
The following catalog has gaps in its page numbers, or doesn't have any numbers. We have chosen to leave the page numbering in the order that Acrobat assigns it.




OPERATOR'S MANUAL AND PARTS CATALOG

FOR

KB-KR

SERIES

ELECTRIC GENERATING SETS



PARTS AVAILABILITY
LONGER GUARANTEED

ISSUE DATE


1NS, NS76 (Replaces 8NS, NS74)

PARTS CATALOG

INSTRUCTIONS FOR ORDERING REPAIR PARTS

ONAN PARTS

All parts in this list are Onan parts. For parts or service, contact the dealer from whom you purchased this equipment or your nearest authorized service station. To avoid errors or delay in filling your order, please refer to the Onan nameplate and give the complete MODEL, SPECIFICATION and SERIAL number.



INTERNATIONAL HARVESTER PARTS

All International Harvester parts must be ordered from the International Harvester Company, Chicago, Illinois or the nearest International Harvester Construction Equipment distributor or dealer.

Refer to the International Harvester nameplate. When ordering parts or requesting service information supply all information stated on engine nameplate and engine serial number which is stamped on front of cylinder head.

NTERN		H	FAMERICA BY HARVESTER LLINOIS	co
MODEL				
SERIAL NO.				
MAX. IDLE SPEED		FU LO SP E	AD	
	DO NOI	OVI	ERLOAD	

This catalog applies to the standard Onan KB and KR Series units as listed below. Powered by an International Harvester's Manual). Engine parts modified or added by Onan will be in this list and have Onan part numbers. These supersede similar parts listed in the International Harvester manual.

Onan parts are arranged in groups of related items and are identified by a reference. All parts illustrations are typical. Using the Model and Spec No. from the Onan nameplate, select Parts Key No. (1, 2, etc., in the last column) that applies to your set MODEL and SPEC NO. This PARTS KEY NO. represents parts that differ between models. Unless otherwise mentioned, parts are interchangeable. Right and left sides are determined by facing the front end of the engine.

GENERATING SET DATA TABLE

MODEL & SPEC NO.*		ELECTRIC	CAL DATA		PARTS KEY
	WATTS	HERTZ	PHASE	WIRE	
45.0KB-515R/ 55.0KB-515R/	45,000 55,000	50 50	**	12 12	
55.0KB-15R/ 55.0KB-9XR/	55,000 55,000	60 60	3	12 4	1
65.0KB)15R/ 65.0KB-9XR/	65,000 65,000	60 60	3	12 4	
70.0KR-515R/ 70.0KR-15R/	70,000 70,000	50 60	**	12 12	
85.0KR-15R/ 85.0KR-9XR/	85,000 85,000	60 60	3	12 4	2
Pennsylvania Approved Models	See S	Special Parts Li	st Following the	Standard Pa	rts List.

^{* -} The Specification Letter advances (A to B, B to C, etc.) with manufacturing changes.

REPLACEMENT ENGINE

100-0854 1 100-0855 1 ★Engine. Replacement - KB - International Harvester Company Model UV-401

*Engine, Replacement - KR - International Harvester Company Model UV-549.

General Description:


Includes - Complete Cylinder Block, Oil Pan, Water Pump, Oil Filter, Governor, Exhaust Manifolds, and Engine Mounts.

Excludes - Carburetor, Fuel Pump, Air Cleaner, Fuel Filter, Starter & Solenoid, Charge Generator, Regulator & Wire Harness, Ignition Coil, Distributor, Spark Plug Leads, Oil Pressure & Water Temperature Gauge Senders, Oil Pressure Switch, High Water Temperature Cut Off Switch, Anti-Dieseling Control, Radiator, Fan Blades & Belt, Exhaust Header, Muffler and Exhaust Tube.

* - Standard generator set, for all other models refer to factory.


 ⁻ These sets are reconnectible; refer to Table 2 Voltage Connections.

COOLING SYSTEM GROUP




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	RADIATOR- 130-0430	-INCLUDE	Key 1 (55.0KB)	12	505-0019	1	Bushing, Drain Valve (1/2 x 3/8")
2	130-0429 130-0449	1 1	Key 1 (65.0KB) and Key 2 Cap, Radiator - 7 lbs.	13	102-0431	1	Cooler, Oil - Key 1 (65.0KB Only)
. 8	603-03 32	2	Pressure Hose, Radiator - Upper	14	102-0434	1	Gasket, Rear - Oil Cooler - Key 1 (65.0KB Only)
4	503-0333 503-0311	1 4	Hose, Radiator - Lower Clamp, Upper Hose	15	102-0435	1	Gasket, Front - Oil Cooler - Key 1 (65.0KB Only)
6	503-0354 130-0428	2 1	Clamp, Lower Hose Fan Only, Cooling	16	503-0399	1	Elbow, Water By-Pass - Oil Cooler - Key 1 (65.0KB Only)
8	511-0059 130-0434	2 1	Belt, Fan Drive Guard, Fan (LH) - Also used	17	503-0398	2	Clamp, Hose - Oil Cooler - Key 1 (65.0KB Only)
	•		on City Water Cooled Sets without water cooled	18	502-0250	1	Elbow, Hose - Oil Cooler - Key 1 (65.0KB Only)
10	130-0433	1	manifold Guard, Fan (RH) - Also used	19	102-0494	1	Nipple, Oil Cooler - Key 1 (65,0KB Only)
		× *	on City Water Cooled Sets without water cooled manifold	2 0	130-0798 ·	1	Adapter, Fan Guard - City Water Cooled without water cooled manifold
_ 11	504-0028	1	Valve, Drain	<u>}</u> 21	821-0010	As Req.	

OIL DRAIN, BREATHER, AIR CLEANER, SENDERS, GOVERNOR, AND OPTIONAL RESERVOIR (DAY) TANK GROUP




REF. NO.		QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	140-0524	1	Cleaner, Air - Gasoline	22	151-0387	1	Gasket, Governor Flange
•			Fueled Models	23	505-0099	1	Nipple, Close, Breather
2	140-0525	1	Adapter, Air Cleaner				Hose Adapter
3	102-0034	1	Gasket, Oil Drain Adapter	24	505-0038	1	Elbow, Breather Hose Adapter
4	102-0033	1	Adapter, Oil Drain	25	151-0371	1	*Governor Assembly (Inter-
5	502-0133	1	Elbow, Oil Drain (90°)				national Harvester Co.
6	505-0100	2	Nipple, Oil Drain (1/2")				#678045C91)
7	504-0011	1	Valve, Shut-Off - Oil Drain	26	123-0960	1	Vent, Crankcase
8	503-0197	1	Clamp, Oil Drain Hose	27	332-1281	1	Bracket, Terminal Mounting
9	503-0098	1	Hose, Oil Drain	28	870-0196	1	Nut, Insulator
10	193-0108	1	Sender, Oil Pressure Gauge	29	508-0015	1	Washer, Insulator
11	193-0104	1	Sender, Water Temperature	30	809-0035	1	Screw, Sheet Metal
			, Gauge	31	140-0851	1	Cleaner, Air - Gaseous
12	, 309-0178	1 (Y Switch, Water Temperature (7) (High) Pre-ALAZA (57)				Fueled Models
	7		(High) Pre-ALARA)	32	140-0871	1	Element, Air Cleaner -
T 13	309-0169	1	Switch, Oil Pressure				Gaseous Fueled Models -
14	509-0059	1	Tee, Pipe (1/8") Oil				Optional
- 1			Pressure Switch and Oil	33	504-0085	1	Valve, Fuel Shut-Off -
1			Gauge Sender Mounting				Optional
15	505-0104	1	Nipple, Close (1/8 x 1-1/2") - Oil Pressure Tee to Block	34	308-0005	1	Switch, Gas-Gasoline - Optional
16	140-0518	1	Cleaner, Crankcase Breather	35	308-0150	1	Bracket, Switch Mounting -
17	505-0369	1	Coupling, Reducer (1/2 x				Optional
'			1/4") - Breather Cleaner	36	309-0269	1	Switch, Low Engine Temperature
1			to Mounting Nipple		141-0640	1	Repair Kit, Carburetor
18	505-0099	1	Nipple, Close (1/4 x 7/8") -		141-0641	1	Gasket Kit, Carburetor
1			Breather Cleaner to Cylinder				
1			Head Cover Mounting				ts for this governor (International
19	503-0445	1	Hose, Breather		,		ernational Harvester Company,
20	503-0131	2	Clamp, Breather Hose	40	1 North Michi	gan Aven	ue, Chicago, Illinois 60611.
21	505-0010	1	Nipple, Half (1/4 x 1")				
			Breather Hose Adapter				
-12	309-0129		1 Frith, Tomo (51)				

Shorthy (S1)
Shorthy
RESERVOIR (DAY) TANK GROUP



GASOLINE FUEL SYSTEM, EXHAUST, AND ANTI DIESELING GROUP




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION	
1	504-0095	1	Valve, Shut-Off - Carburetor Inlet - Key 1 - Spec N Only	29	304-0015	2	Washer, Resistor Centering - Spec N Only	
1	502-0004	1	Elbow, Male - Carburetor	30	155-0612	1	Header Assembly, Exhaust	
			Inlet - Key 1 - Begin Spec P	31	31 133-0157 2 Shield,		Shield, Exhaust Manifold Heat	
1	502-0004	1	Elbow, Male - Carburetor	32	520-0599	2	Stud, Exhaust Elbow	
. 2	516-0086	1	Inlet - Key 2 †Pin, Roll (1/8 x 3/4") -	33	145-0414	1	Link, Throttle Spring - Begin Spec P	
3	309-0133	1	Spec N Only Actuator, Micro Switch -	34	145-0436	1	Link, Solenoid - Begin Spec P	
			Spec N Only	35	SOLENOID,	ANTI-DIE	SELING	
4	309 -0155	1	Switch, Micro - Spec N Only		307-1093	1	Spec P to Serial #1173734206 During Spec R)	
5	309- 0131	. 1	Bracket, Micro Switch Mounting - Spec N Only		307-1356	1	Begin Serial #1173734206 During Spec R)	
6	*CARBURET	FOR ASSE	MBLY	36	SCREW, RO	UND HEAL	D	
	141-0636	1	Key 1 (Zenith #28ADA10C)		812-0079	4	Solenoid Mounting	
	141-0635	1	Key 2 (Zenith #12411A)		813-0100	. 2	Throttle Spring Bracket	
7	307-0259	1	Solenoid & Lead Assembly,				Mounting	
			Anti-Dieseling - Spec N Only		813-0148	1	Link Mounting - Begin Spec P	
8	145-0124	1	Link, Solenoid - Spec N	37	WASHER, F	LAT		
			Only		526-0115	4	Carburetor Mounting	
9	145-0186	1	Bracket, Solenoid Mounting	_	526-0018	2	Link Mounting - Begin	
10	150-0302	1	Bushing, Throttle Spring	•			Spec P	
			Link to Ball Joint	38	WASHER, L	OCK	·	
11	145-0118	1	Link, Throttle Spring -		850-0 045	4	Carburetor Mounting	
			Spec N Only		850-0025	4	Solenoid Mounting	
12	145-0158	1	Spring, Throttle		850-0040	2	†Ball Joint Mounting -	
13	150-0096	1	Stud, Throttle Spring				Begin Spec P	
			Adjusting	39	NUT, HEX	•		
14	145-0187	1	Bracket, Throttle Spring		860-0008	4	Solenoid Mounting	
15	145-0410	1	Body Assembly, Throttle (Includes Parts Marked †)		870-0131	2	Throttle Spring Bracket Mounting	
16	150-0638	2	†Joint, Ball (3 Used Spec N		870-0053	2	Throttle Adjusting Stud	
17	115-0025	4	Only) †Nut, Hex (1/4-28) -	40	3 07 - 1323	1	Bracket, Solenoid Mounting - Begin Serial #1173734201	
			(2) Governor Control Stud, (2) Ball Joint, (5 Used	41	307-1330	1	During Spec R Bracket, Solenoid - Begin	
18	145-0189	1	Spec N Only) Gasket, Carburetor to				Serial #1173734206 During Spec R	
19	145-0185	1	Solenoid Mounting Bracket Gasket, Throttle Body	42	152-0155	1	Swivel, Solenoid - Begin Serial #1173734206 During Spec R	
20	309-0132	1	Cam, Micro Switch - Spec N	43	526-0006	2	Washer, Flat	
			Only	44	516-0059	1	Pin, Cotter	
21	110-0445	4	Nut, Hex (5/16-24) - Carburetor Retaining	45	815-0104	1	Screw, Fillister Head (8-32 x 5/16" long)	
22	520-0517	1	†Stud, Governor Control	46	800-0003	2	Screw, Hex Head	
23	141-0372	1	Knob, Choke - Carburetor				(1/4-20 x 1/2" long)	
24	149-0730	. 1	Pump Assembly, Fuel	47	850-0040	4	Washer, Lock (1/4)	
25	149-0736	1	Gasket, Fuel Pump Mounting	48	862-0001	2	Nut, Hex (1/4-20)	
26	159-0685	1	Line, Fuel Pump to Carburetor	* - Fo		s contact v	our nearest Zenith Carburetor	
27	502-0004	1	Elbow, Inverted Male - Fuel Pump Outlet	de	aler or Zenith	Carbureto	or Division, The Bendix Corp.,	
. 28	304-0045	1	Resistor, Anti-Dieseling (Fixed) - Spec N Only	696 Hart Avenue, Detroit, Michigan.† - Included in 145-0410 Throttle Body Assembly.				


IGNITION GROUP


REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION
1	166-0282	1	*Distributor Assembly
_			(Delco Remy #1110625)
2 3	166-0278	1	Coil, Ignition (12 Volt)
3	166-0279	1	Bracket, Coil Mounting
4	133-0158	1	Shield, Ignition Coil Heat
5	166-0286	1	Screw, Oil Bracket
6	166-0321	1	Point Set, Breaker
7	160-0558	10	Nipple, Rubber (9) Distri- butor, (1) Ignition Coil
8	336-0332	1	Lead, Ignition Coil
9	312-0058	i	Condenser, Ignition Coil
9	312-0036	1	(0.1 Mfd.)
10	CABLE, BAT	TERY	, ,
	416-0643	1	28-1/4" Long
	416-0021	1	20-1/2" Long
11	167-1528	1	Cable, Distributor
			(Includes Suppressor)
12	314-0006	1	Suppressor, Distributor
13	166-0320	1	Condenser, Distributor
14	CABLE, SPA	ARK PLUC	3
	167-1332	. 1	Cylinder No. 1
	167-1333	1	Cylinder No. 2
	167-1334	1	Cylinder No. 3
	167-1337	1	Cylinder No. 4
	167-1335	1	Cylinder No. 5
	167-1336	1	Cylinder No. 6
	167-1338	1	Cylinder No. 7
	167-1339	1	Cylinder No. 8
15	166-0318	1	Cap, Distributor
16	166-0319	1	Rotor, Distributor
17	800-0026	2	Screw, Hex Cap - Coil
			Clamp Mounting
18	850-0045	2	Washer, Lock - Coil Clamp
_		_	Mounting
19	862-0015	2	Nut, Hex - Coil Clamp
	.07.0407		Mounting
20	167-0127	8	Plug, Spark

^{* -} For components not listed, contact your nearest Delco Remy dealer or Delco Remy Division of General Motors Corp., Anderson, Indiana 46011.



STARTING MOTOR AND BATTERY CHARGE GENERATOR GROUP






REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION
1	191-0486	1	*Motor, Starting (12 Volt) (Delco Remy #1113167-H)
2	511-0025	1	Belt, Alternator Drive
3	312-0058	1	Condenser (0.1 Mfd.) - Charge Alternator
4	337-0090	2	Strap, Ground (8-7/16")
5	191-0665	1	**Alternator, Charge (Includes Regulator) - Motorola #70D44039B
6	191-0649	1	Pulley, Alternator
. 7	191-0678	1	Brace, Alternator Mounting
8	191-0725	1	Guard, Alternator Belt
9	191-0732	1	Regulator, Alternator (Part of Alternator)
10	SCREW, HI	EX CAP	ŕ
ķ	800-0051	2	Starter Motor Mounting
	800-0051	. 3	Alternator Mounting (3/8-16 x 1-1/4")
ł	800-0095	1	Alternator Mounting (1/2-13 x 2-1/4")
Į	800-0025	6	Alternator Guard Mounting
F.	800-0091	1	Ground Strap Mounting (1/2-13 x 1-1/4")

REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
11	WASHER, LO	CK	
	850-0050	3	Alternator Mounting (3/8")
	850-0060	1	Alternator Mounting (1/2")
	850-0045	6	Alternator Guard Mounting
	856-0013	1	Ground Strap Mounting (1/2") EIT
	850-0060	1	Ground Strap Mounting (1/2")
12	526-0115	6	Washer, Flat - Alternator Guard Mounting
13	NUT, HEX		•
	862-0015	6	Alternator Guard Mounting
	862-0005	1	Alternator Mounting (1/2-13")
	862-0003	3	Alternator Mounting (3/8-16")
	862-0016	1	Ground Strap Mounting (1/2-13")
14	856-0010	2	Washer, Shakeproof - Starter Motor Mounting

^{* -} For components contact your nearest Delco Remy dealer or Delco Remy Div. of General Motors Corp., Anderson, Indiana 46011.


For components contact your nearest Motorola dealer or Motorola Automotive Products Inc., 9401 W. Grand Avenue, Franklin Park, Illinois 60131.

MOUNTING GROUP (UNHOUSED MODELS ONLY)




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
NO. 1 2 3 4 5 6 8 9 10 11 12 14	403-0893 405-1153 403-0896 403-0897 405-1165 416-0338 520-0231 800-0520 402-0371 301-3155 301-3156 301-3154	1 1 1 1 1 2 2 2	Chassis, Mounting Panel, Front End (Radiator Cooled Models) Trim, Chassis - Right Hand Side Trim, Chassis - Left Hand Side Hood, Radiator Extension Frame, Battery Hold-down Stud, Battery Hold-down Stud, Battery Hold-down Bolt, Generator End Mounting (3/4-10 x 1") Rubber, Generator End Mounting Housing, Control Box Panel, Control Box Housing Saddle, Control Box Housing	16 17 18 19 20 21 22 23 24 25 26 27 28 29 30	821-0014 870-0113 870-0020 821-0010 800-0003 526-0018 850-0040 862-0001 815-0026 853-0008 526-0015 850-0045 865-0007 850-0055 800-0071 402-0214	As Req. As Req. 6 As Req. 4 18 18 2 2 2 4 4 2	Nut (5/16-18), Sq. Weld.
15	508-0001	1	Grommet, Control Box Saddle				

HOUSING GROUP (HOUSED MODELS ONLY)




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	403-0893	1	Chassis, Mounting	21	301-3155	1	Housing, Control Box
2	405-1153	1	Panel, Front End	22	301-3156	3	Panel, Control Box Housing
3	406-0105	8	Clamp, Hold-down - Side	24	301-3154	1	Saddle, Control Box Housing
			Panels	25	508-0001	1	Grommet, Control Box Saddle
4	403-0894	1	Chassis, Mounting - Rear	26	821-0014		Screw (5/16-18 x 1/2), Lock
			Section	27	870-0113	As Req.	Nut (5/16-18), Retainer
5	405-1775	1	Panel, Rear End - Excludes Door	28	821-0010	As Req.	Lock
6	405-1776	2	Support, Top Panel	29	850-0050	6	Washer (3/8"), Lock
7	405-1774	2	Panel, Door - Housing Side -	30	800-0048	6	Screw (3/8-16 x 3/4")
			includes Handles	31	800-0003	4	Screw (1/4-20 x 1/2).
8	405-1778	2	Panel, Side				Control Box to Saddle
9	PANEL, TOP		•	32	526-0018	8	Washer (1/4")
	405-1779	1	Models Without Water Cooled	′ 3 3	850-0 040	4	Washer (1/4"), Lock
			Manifolds	34	862-0001	4	Nut (1/4-20)
	405-1813	1	Models With Water Cooled	3 5	815-0026	18	Screw (10-32 x 3/8)
			Manifolds	36	853-000 8	18	Washer, ET Lock (#10)
10	405-1780	1	Panel, Chassis	37	526-00 15	2	Washer (5/16")
11	416-0338	1	Frame, Battery Hold-down	38	850-004 5	2	Washer (5/16"), Lock
13	520-0231	2	Stud, Battery Hold-down	39	865-00 07	2	Nut, Wing (5/16-18)
14	405-1777	1	Door, Rear Panel Control	40	850-0055	4	Washer (7/16"), Lock
15	406-0157	1	Handle, Panel Door (Includes	41	800-0071	4	Screw (7/16-14 x 1)
			Keys)	42	402-0214	2	Bolt, Front Engine Mounting
17	800-0520	2	Bolt, Generator End Mounting	43	813-0098	22	Screw (10-32 x 3/8)
			(3/4-10 x 1")	44	850-00 30	2 2	Washer (#10), Lock
18	402-0371	2	Rubber, Generator End	45	870-0053	16	Nut (10-32)
			Mounting	46	821-0006	3.	Screw (#14 x 1/2), Pan
19	406-0089	1	Catch, Panel Door	•			Head Sheet Metal
20	403-0895	2	Cover, Conduit Opening	47	870-0106	3	Nut, Speed



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	PANEL ONL	Y, ENGINE		18	MONITOR.	ENGINE C	ONTROL (See Separate Group for
	301-3165	1	Models With One Fault Light		Component	s)	
	301-3267	.1	Models With Five Fault		300-0679	1	Models With One Fault
		,	Lights - Optional				Light - Standard
2	301-3253	1	Bracket, Engine Control		300-0681	1	Models With Five Fault
` 3	308-0138	1	Switch, Selector				Lights - Optional
4	308-0002	1	Switch, Panel Light	19	HARNESS A	SSEMBLY	, WIRING - CONTROL
5	193-0107	1	Gauge, Oil Pressure		(Includes Pa	rts Marked	! *)
6	193-0106	1	Gauge, Water Temperature		338-0528	1	Models With One Fault
7	302-0061	1	Ammeter, Charge (30-0-30)				Light - Standard
8	332-1239	1	Strip, Marker (B+, Remote,		338-0534	1	Models With Five Fault
			Ground, Alarm)				Lights - Optional
9	332-1241	1	Strip, Marker (21 through 36)	20	332-0537	1	*Block, Terminal - 4 Place
10	308-0003	1	Plate, Switch (on-off)	21	332-0795	1	*Block, Terminal - 16 Place
11	332-1276	2	Plug, Keying	22	323-0765	2	Socket, Relay - 11 Place
12	307-1058	2	Relay (1) Start Disconnect,	23	332-1271	2	*Housing, Printed Circuit
			(1) Ignition				Board Terminal
13	307-1031	1	Relay, Start Solenoid	24	332-0051	1 .	Clip, Tinnerman
14	322-0073	1	Holder, Lamp	25	338-0505	1	Harness Assembly, Wiring -
15	322-0074	1	Lamp, Panel				Engine to Control
16	LAMP, FAUL	_T	•	26	357-0004	1	Rectifier, Diode (Part of
	322-0128	1	Standard Sets				Standard Cranker Control)
	322-0107	1	Overcrank (Optional)	27	323-0764	1	*Socket, Relay - 8 Place
	322-0111	1	Overspeed (Optional)	28	332-1269	As Req.	*Terminal, Printed Circuit
	322-0108	1	Low Oil Pressure (Optional)				Board
	322-0109	1	High Engine Temperature	29	332-1280	As Req.	*Terminal, Crimp
			(Optional)	30	332-1043	1	*Jumper, Terminal Model With
	322-0110	1	Low Engine Temperature				One Fault Light
			(Optional)	31	307-1061	1	Relay, Starter Protection -
17	CONTROL,	CRANKER					Begin Spec P
	300-0733	1	Standard Cranker	32	332-0699	1	*Block, Terminal (6 Place) -
	300-0714	7	Cycle Cranker (Optional)				Models With Five Fault
			 See Separate Group for 				Lights
			Components	33	332-1240	1	*Strip, Marker (53 thru 58) - Models With Five Fault Lights
				34	307-1157	3	Spring, Relay Hold-down


^{* -} Included in Wiring Harness Assembly.




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF.		QTY. USED	PART DESCRIPTION
- 1	301-3158	1	Box Only, Control	6	STRIP, MAR	KER	
2	PANEL ONL'	Y, CONTR	OL		332-1248	1	Models Without Meter Panel
			Models Without Meter Panel		332-1242	1	Models With Meter Panel
	301-3168	1	45.0KB-515R, 55.0KB-515R,	7	315-0342	1	Transformer, Voltage
			55.0KB-15R, 65.0KB-15R,	8	303-0032	1	Knob, Rheostat
			70.0KR-515R, 70.0KR-15R	9	303-0076	1	Knob, Selector Switch
			and 85.0KR-15R	10	SWITCH, SE	LECTOR	
	301-3341	1	55.0KB-9XR, 65.0KB-9XR		308-0012	1	Models Without Meter Panel
			and 85.0KR-9XR		308-0284	1	Models With Meter Panel
			Models With Meter Panel	11	303-0170	1	Rheostat
	301-3170 -	1	45.0KB-515R, 55.0KB-515R, 55.0KB-15R, 65.0KB-15R, 70.0KR-515R, 70.0KR-15R and 85.0KR-15R	12	350-0556	1	*Resistor (47,000-Ohm, 1/2 Watt) 45.0KB-515R, 55.0KB-515R, 55.0KB-15R, 65.0KB-15R, 70.0KR-515R, 70.0KR-15R
	301-3342	1	55.0KB-9XR, 65.0KB-9XR				and 85.0KR-15R
	,		and 85.0KR-9XR	13	VOLTMETE	3	
3	402-0078	4	Rubber, Mounting - Control Box		302-0718	1	45.0KB-515R, 55.0KB-515R, 55.0KB-15R, 65.0KB-15R,
4	337-0049	1	Strap, Ground				70.0KR-515R, 70.0KR-15R
5	BREAKER, C	CIRCUIT					and 85.0KR-15R
	320-0018	1 🐬	Spec N Only		302-0779	1	55.0KB-9XR, 65.0KB-9XR
	320-0431	1	Begin Spec P (Also used on Spec N optional brushless generator sets)				and 85.0KR-9XR


REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
14	307-1061	1	Relay, Voltage Selector -	29	302-0729	1	Bracket, Transformer Mounting
, ,	00. 100.	•	45.0KB-515R, 55.0KB-515R,	30	302-0235	3	Clamp, Transformer Mounting -
			55.0KB-15R, 65.0KB-15R,			_	Upper - Models With Meter
			70.0KR-515R, 70.0KR-15R				Panel
			and 85.0KR-15R	31	302-0236	3	Clamp, Transformer Mounting -
15	322-0130	7	Light, Lower Scale -				Lower - Models With Meter
			45.0KB-515R, 55.0KB-515R,				Panel
			55.0KB-15R, 65.0KB-15R,	32	302-0253	As Req.	Shim, Transformer Mounting
			70.0KR-515R, 70.0KR-15R	33	*BLOCK, TE	RMINAL	•
			and 85.0KR-15R		332-0607	1	Models Without Meter
16	322- 0131	1	Light, Upper Scale -				Panel - 12 Place
			45.0KB-515R, 55.0KB-515R,		332-0795	1	Models With Meter Panel -
			55.0KB-15R, 65.0KB-15R,				16 Place
			70.0KR-515R, 70.0KR-15R	34	323-0764	1	*Socket, Relay -
			and 85.0KR-15R				45.0KB-515R, 55.0KB-515R,
17	301-3244	1	Bracket, Relay Mounting -				55.0KB-15R, 65.0KB-15R,
			45.0KB-515R, 55.0KB-515R,				70.0KR-515R, 70.0KR-15R
			55.0KB-15R, 65.0KB-15R,	35	332-1280	A - D	and 85.0KR-15R
			70.0KR-515R, 70.0KR-15R and 85.0KR-15R	35	332-1260	As neq.	*Terminal, Crimp -
18	BOARD ACC	EMPI V D	RINTED CIRCUIT (See				45.0KB-515R, 55.0KB-515R, 55.0KB-15R, 65.0KB-15R,
10	Separate Gro						70.0KR-515R, 70.0KR-15R
	332-1264	1	Spec N Only				and 85.0KR-15R
	332-1268	1	Begin Spec P (Also used on				and 85.0KR-15R
	332-1200	,	Spec N optional brushless	36	307-1157	1	Spring, Relay Hold-down
			generator sets	37	302-0307	i	Lock, Circuit Breaker
19	HARNESS V	VIRING - A	C CONTROL (Includes Parts			•	Handle - Penn State Models
	Marked *)						(Optional)
	,		Models Without Meter Panel	38	315-0384	1	Reactor Assembly, Commutator
	338-0524	1	45.0KB-515R, 55.0KB-515R,				Begin Spec S
			55.0KB-15R, 65.0KB-15R,	39	305-0524	1	Bridge, Rectifier - Begin
			70.0KR-515R, 70.0KR-15R				Spec S
			and 85.0KR-15R	40	813-0110	6	Screws, Round Head Machine
	338-0 570	1	55.0KB-9XR, 65.0KB-9XR				(10-32 x 2" long)
			and 85.0KR-9XR	41	854-0010	8	Washer, Internal Lock (#10)
			Models With Meter Panel	42	815-0203	1	Screw, Round Head (BM)
	338-0525	1	45.0KB-515R, 55.0KB-515R,	40		•	(10-32 x 7/8" long)
			55.0KB-15R, 65.0KB-15R,	43	871-0010	3	Nut, Hex (BMS) - (10-32)
			70.0KR-515R, 70.0KR-15R	44	526-0049	2	Washer, Flat
	220 0571	-	and 85.0KR-9XR 55.0KB-9XR, 65.0KB-9XR	45	856-0003	1	Washer, External/Internal -
	338-0571	1	and 85.0KR-9XR	46	HADNESS	MIDING - A	Lock CCONTROL (Models Without Meter
20	332-0050	2	Clip. Tinnerman	40		GINSPECS	
21	406-0332	2	Fastener		338-0764	1	45.0KB-515R, 50.0KB-15R (Penn
22	406-0333	2	Stud, Fastener		000 0.01		State) -55.0KB-15R. 55.0KB-515R,
23	406-0334	2	Washer, Stud Fastener				65.0KB-15R, 70.0KR-515R,
24	508-0001	4	Grommet				70.0KR-15R, 75.0KR-15R
25			ME (Models With Meter Panel)				(Penn State), 85.0KR-15R
	302-0469	1	50 Hertz		338-0766	1	55.0KB-9XR, 65.0KB-9XR,
	302-0466	1	60 Hertz				70.0KR-9XR, 85.0KR-9XR
26	METER, FRE	EQUENCY	(Models With Meter Panel)				Models With Meter Panel
	302-0256	1	50 Hertz		338-0730	1	45.0KB-515R, 50.0KB-15R
	302-0221	1	60 Hertz				(Penn State), 55.0KB-15R,
27		AC (Mode	els With Meter Panel)				55.0KB-515R, 65.0KB-15R,
	302- 0720	1	Key 1 ~ 45.0KB (0-100/0-200 Amps)				70.0KR-515R, 70.0KR-15R,
	302-0721	1	Key 1~55.0KB (0-150/0-300 Amps)				75.0KR-15R (Penn State),
	302-0722	1	Key 1 - 65.0KB - AND Key 2		000 0750		85.0KR-15R
	TDANCECO	MED OUT	(0-200/0-400 Amps)		338-0759	1	55.0KB-9XR, 65.0KB-9XR,
28	TRANSFOR						70.0KR-9XR, 85.0KR-9XR
	302-0106 302-0107	3 3	Key 1 (45:0KB) - 200/5 Key 1 (55:0KB) - 300/5		Included :-	Miring Ha-	ness Assembly.
	302-0107 302-0608	3	Key 1 (65.0KB) - 300/5 Key 1 (65.0KB) AND Key 2 -	-	mended in	withing man	ness masembly.
	302-0000	3	400/5				
•							


GENERATOR GROUP





VOLTAGE CHASSIS ASSEMBLY





REF.	PART NO.	QTY. USED	PART DESCRIPTION		IEF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
110.		1	Rotor Assembly, Wound	_	15	234-0361	1	Wrapper, Generator End
•		•	(Includes Parts Marked †)	;				Bell - Unhoused Sets
2	205-0089	1	†Blower		16	509-0125	1	Seal, "O" Ring - Bearing
-	510-0101		†Bearing		17	526-0238	1	†Washer, Bearing Retainer
3	210-0101	1	Stator Assembly, Wound		18	800-0513	1	†Screw, Bearing Retainer
4	005 0000	8	†Bolt, Place - Drive Disc		19	STUD, GENE	RATOR 1	THROUGH
5	805-0033	•	to Hub			520-0722	4	45.0KB - 55.0KB
_	500 0050	8	*Washer (5/8")			520-0723	4	65.0KB
6	526-025 9	8	Bolt, Place - Drive Disc			520-0724	4	70.0KR
7	805-0032	•	to Engine			520-0726	4	85.0KR
_			Switch Assembly, Overspeed		20	150-1456	1	Bracket and Point Assembly,
8	150-0717	3			20	100 1 100		Overspeed Switch - Begin
9	211-0185	1	Bell, End					Spec S
10	234-0368	1	Screen, Generator		24	800-0003	2	Screw (1/4-20 x 1-1/4") -
11	232-2106	2	Bracket, Generator Mounting		21	800-0005	-	Bracket Mounting
12	850-0079	1	†Washer (3/4"), Lock		~~	850-0040	8	Washer (1/4"), Lock
13	232-2078	1	†Disc, Generator Drive		22	800-0008	2	Screw (1/4-20 x 1-1/4") -
14	234-0370	1	Grille, Generator Air Inlet -		23	500-000		Screen Mounting
<u>é.</u>			Unhoused Sets	j				00/60// 10/03/////3


46

)

FREF.	PART NO.	OTY.	PART DESCRIPTION	,	REF.	PART NO.	QTY. USED	PART DESCRIPTION
24	800-0009	4	Screw (1/4-20 x 1+1/2") -	40 0	59	CHASSIS A: 305-0489	SSEMBLY 1	- INCLUDES PARTS MARKED \$
25	862-0001	2	Stator Mounting Nut (1/4-20) - Generator			305-0483	1	55.0KB - Spec N Only 65.0KB, 70.0KR and 85.0KR -
26	812-0189	1	Screen Screw (3/8-16 x 3/4"),			305-0491	1	Spec N Only £Spec P through R
			Round Head - Overspeed Switch Mounting		60	305-0481	2	Spacer, Voltage Regulator Chassis Mounting - Spec P
27	8 56-0010	1	Washer (3/8"), Shakeproof EIT		61	853-0013	4	through R Washer (1/4"), Shake-
28	862-0011	4	Nut (3/8-16) - Generator Through Stud		62	800-0009	2	proof ET Screw (1/4-20 x 1-1/2") -
29 31	850-0050 201-1720	4 1 :	Washer (3/8")		63	305-0482	1	Chassis Assembly Mounting ‡Chassis, Voltage Regulator
	201-1739 +PECTIFIED		£†Rotor Assembly, Wound - Exciter (Includes Diodes) Part of Exciter Rotor)		64	358-0029		£‡Rectifier, Silicon (Avalanche) - Negative
JŁ	358-0015	3	£Negative		65	‡RECTIFIER	SILICON	GATE CONTROL - NEGATIVE
	358-0016	3	£Positive			364-0012	2	Spec N Only
33			Part of Exciter Rotor)			364-0014	2	£Spec P through R
	363-0055	1 `	For Negative Diodes		6 6	£RECTIFIER	SILICON	(Avalanche) - NEGATIVE
	363-0054	1	For Positive Diodes			358-0031	2	Spec N Only
34	870-0053	6	Nut (10-32) - Diode Mounting			358-0035	2	£Spec P through R
35	850-0030	6	Washer (#10) - Diode Mounting		67	363-0048	3	‡Heat Sink, Rectifier
36	813-0110	4	Screw (10-32 x 2"), Round		68	332-1043	2	‡Jumper, Terminal Board
			Head - Heat Sink Mounting		69	508-0002	2	‡Grommet, Reactor Leads
37	526-0009	4	Washer (#10)		70	332-1266	1	‡Block, Terminal
38	332-0050	2	Clip, Wire		71	#REACTOR	ASSEMBL'	_
39	508-0124	4	Bushing, Insulating			315-0341	1	55.0KB - Spec N Only
40	508-0156	4	Washer, Insulating			315-0339	1	65.0KB, 70.0KR and 85.0KR -
41	850-0030	4	Washer (#10)					Spec N Only
42	870-0053	4	Nut (10-32) - Heat Sink			315-0343	1	£Spec P through R
			Mounting		72	332-126 5	6	‡Insulator, Heat Sink
43			WOUND-EXCITER				_	Mounting
	220-1528	1	Spec P through R		73	150-0723	1	‡Contact, Overspeed Switch
	220-2353	1	Spec S		74	870-0250	1	‡Nut, Insulator - Overspeed
44	232-2102		£†Spacer, Bearing		75	000 0004	0	Switch
45	515-0145		£†Key, Exciter Rotor		75	862-0001	2	‡Nut (1/4-20), Hex -
46	800-0 073	12	Screw (7/16-14 x 1-1/2") -		76	952 0012	4	Overspeed Switch
			Stator Assembly to		76	853-0013	1	‡Washer (1/4"), Lock ~
47	050 0055	40	Generator Adapter		77	332-1415	1	Overspeed Switch ‡Clamp, Cable
47	850-0 055	12	Washer (7/16"), Lock		78	800-0003	2	Screw (1/4-20 x 1/2") -
48	812- 0146	4	Screw (1/4-20 x 3/8"),		70	800-0003	2	Chassis Assembly Mounting
			Round Head - Air Inlet		79	212-0342	1	Rig Assembly, Brush -
49	850-0040	4	Grille Mounting Washer (1/4"), Lock		13	212-0042	•	Includes Brushes & Springs -
50	8 00-0132	4						Spec N Only
30	000-0132	4	Screw (5/8-11 x 1-1/2") - Generator Support to		80	212-1105	4	Spring, Brush - Spec N Only
			Chassis		81	214-0046	4	Brush - Spec N Only
51	850-0 070	4	Washer (5/8"), Lock		82	204-0083	1	Ring. Collector - Spec N
52	402-0384	2	Mount, Vibration					Only
53	800-0163	2	Screw (3/4-10 x 4") - Vibration Mount to Stator		8 3	212-1225	4	Spacer, Brush Rig Mounting - Spec N Only
			Assembly		84	526-0018	4	Washer, Brush Rig Mounting -
54	800-009 0	4	Screw (1/2-13 x 1") -					Spec N Only
			Generator Support to Vibration Mount		85	503-0611	4	Hose, Insulator
55	850-0060	·4	Washer (1/2"), Lock		* - Re	efer to factory	giving co	mplete Model, Spec and
56	850-0079	2	Washer (3/4"), Lock					Onan Nameplate.
57	526-0238	2	Washer (3/4"), Flat			cluded in Wo		
58	338-0521	1 .	Harness Assembly, Voltage		‡ - In	cluded in the	Voltage R	egulator Chassis
	!		Regulator - Spec F		. As	ssembly (Spec	c P throug	ıh R).
	;		through H			nese parts we ptional Brush		ed on Spec N rators.


;

CONTROL, CYCLE CRANKER GROUP (OPTIONAL EQUIPMENT)



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	300-0714	1	Control, Cycle Cranker - Complete
C1	356-0039	1	Capacitor, Electrolytic (100 Mfd.)
CR1	359-0027	1	Diode, Zener (7.5 Volts)
CR2,3,4	357-0004	3	Rectifier, Diode
Q1,2	362-0008	2	Transistor, Signal
Q3	362-0017	1	Transistor
Q4	362-0026	1	Transistor, Signal
Q5	362-0019	1	Transistor, Power
R1, R4	303-0171	2	Potentiometer (5,000-Ohm)
R2	350-0560	1	Resistor, Fixed (1 Megohm)
R3, R9	350-0548	2	Resistor, Fixed (10,000-Ohm)
R5	350-0558	1	Resistor, Fixed (68,000-Ohm)
R6	350-0420	1	Resistor, Fixed (24,000-Ohm)
R7	350-0546	- 1	Resistor, Fixed (6,800-Ohm)
R8	350-0526	1	Resistor, Fixed (150-Ohm)
R10	350-0500	1	Resistor, Fixed (1.0-Ohm)
R11	352-0152	1	Resistor, Fixed (5 Watt, 2.5-Ohm)
C2	355-0010	1	Capacitor, Dielectric (.0022 Mfd., 100 Volt)


ENGINE CONTROL MONITOR GROUP (SETS WITH FIVE FAULT LIGHTS) OPTIONAL



REF.	PART NO.	QTY. USED	PART DESCRIPTION
NO.			
	300-0681	1	Monitor Assembly, Complete - Engine Control
K1, K2	307-1039	2	Relay
R6	350-0548	1	Resistor (10,000-Ohm)
C2,3,5,6,7,8	355-0005	6	Capacitor (22 Mfd.)
C1	356-0040	1	Capacitor (10 Mfd.)
C4	356-0030	1	Capacitor (1 Mfd.)
CR9	359-0027	1	Diode, Zener
CR1 thru 8.			
11 thru 16,19	357-0004	15	Rectifier, Diode
CR10,17,18,			
20	364-0017	4	Rectifier, Gate Control
Q3.9	362-0003	2	Transistor
Q1,2,7.8	362-0025	4	Transistor, Field Effect
Q4.5.6.			
11 thru 14	362-0008	8	Transistor, Silicon
R5.14	350-0536	2	Resistor (1000-Ohm)
R1	350-0526	1	Resistor (150-Ohm)
R12	350-0552	1	Resistor (22,000-Ohm)
R2.15	303-0169	. 2	Potentiometer
R3	350-0572	1	Resistor (1-Megohm)
R7,13,22,30	350-0505	4	Resistor (2.7-Ohm)
R4,16,19,34	350-0517	4	Resistor (27-Ohm)
R36	350-0584	1	Resistor (10 Megohm)
R8,11,20,21.			
23,24,27,28			
31.33	350-0529	10	Resistor (270-Ohm)
R9,10,17,18,			
25,26,29,32		8	Resistor (2,200-Ohm)
R35	350-1128	1	Resistor (220-Ohm)
S1	308-0280	1	Switch, Push Button
			•

PRINTED CIRCUIT BOARD ASSEMBLY GROUP (AC)

332-1264 - Printed Circuit Board, Complete BRUSH TYPE GENERATOR




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	OTY. USED	PART DESCRIPTION
TB1 C1	332-1252 355-0018	1 1	Terminal Block Capacitor (.47 Mfd., 100 Volt)	R6	353-0039	1	Resistor, Fixed (5,000-Ohm, 15 Watt)
C2, C7 C3, C9 C4 C5, C8	355-0005 355-0017 355-0006 355-0016	2 2 1 2	Capacitor (.22 Mfd., 200 Volt) Capacitor (.47 Mfd., 400 Volt) Capacitor (.47 Mfd., 200 Volt) Capacitor (1 Mfd., 100 Volt) Capacitor (1 Mfd., 200 Volt)	R7 R8, R16 R9, R10 R11	350-0398 350-0447 350-0423 352-0151	1 2 2 1	Resistor (3,000-Ohm, 1/2 Watt) Resistor (330,000-Ohm, 1/2 Watt) Resistor (33,000-Ohm, 1/2 Watt) Resistor, Fixed (15,000-Ohm, 5 Watt)
C6 C10 C13 CR4 thru 11 CR12 CR13 CR14	355-0015 355-0014 356-0039 357-0014 359-0035 359-0025 359-0026	1 1 8 1 1	Capacitor (.1 Mid., 200 Volt) Capacitor (.047 Mfd., 200 Volt) Capacitor (100 Mfd., 10 Volt) Rectifier, Silicon Diode, Zener (6.8 Volt) Diode, Zener (20 Volt) Diode, Zener (18 Volt)	R12 R13 R14 R15 R17	350-1014 350-1007 350-0443 350-0435 351-0524	1 1 1 1	Resistor (13,000-Ohm, 2 Watt) Resistor (6,800-Ohm, 2 Watt) Resistor (220,000-Ohm, 2 Watt) Resistor (100,000-Ohm, 1/2 Watt) Resistor, Metal Film (13,000-Ohm, 1/4 Watt)
CR15 K1 Q1, Q2	359-0015 307-1063 362-0017	1 1 2	Diode, Zener (24 Volt) Relay, Magnetic Reed Transistor, Silicon (NPN)	R18 R20, R22	303-0168 351-0520	1 2	Potentiometer Resistor, Metal Film (28,000-Ohm, 1/4 Watt)
Q3 R1, R23	361-0004 350-0355	1 2	Transistor, Unijunction Resistor (47-Ohm, 1/2 Watt)	R21	351-0522	1	Resistor, Metal Film (5,110-Ohm, 1/4 Watt)
R1, R23 R2, R3 R4 R5	350-0351 350-1075 353-0040	1 1	Resistor (33-Ohm, 1/2 Watt) Resistor (4.7-Megohm, 2 Watt) Resistor, Fixed (270-Ohm, 10 Watt)	. R24	351-0523	1	Resistor, Metal Film (8,870-Ohm, 1/4 Watt)

PRINTED CIRCUIT BOARD ASSEMBLY GROUP (AC,

332-1268 - Printed Circuit Board, Complete


BRUSHLESS TYPE GENERATOR



REF. NO.	PART NO.	QTY.	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
TB1	332-1252	1	Terminal Block	R6	353-0039	1	Resistor, Fixed (5,000-Ohm,
C1	355-0018	1	Capacitor (.47 Mfd., 100 Volt)	•			15 Watt)
C2, C7	355-0005	2	Capacitor (.22 Mfd., 200 Volt)	R7	350-0398	1	Resistor (3,000-Ohm, 1/2 Watt)
C3, C9	355-0017	2	Capacitor (.47 Mfd., 400 Volt)	R8, R16	350-0447	. 2	Resistor (330,000-Ohm, 1/2 Watt)
C4, C12	355-0006	2	Capacitor (.47 Mfd., 200 Volt)	R9, R10	350-0423	2	Resistor (33,000-Ohm, 1/2 Watt)
C5, C8	355-0016	2	Capacitor (1 Mfd., 100 Volt)	R11	352-0151	1	Resistor, Fixed (15,000-
C6	355-0015	1	Capacitor (.1 Mfd., 200 Volt)				Ohm, 5 Watt)
C10	355-0014	1	Capacitor (.047 Mfd., 200 Volt)	R12	350-1014	1	Resistor (13,000-Ohm, 2 Watt)
C11	355-0020	1	Capacitor (.1 Mfd., 400 Volt)	R13	350-1007	1	Resistor (6,800-Ohm, 2 Watt)
C13	356-0039	1	Capacitor (100 Mfd., 10 Volt)	R14	350-0443	1 1	Resistor (220,000-Ohm, 2 Watt)
CR4 thru 11	357-0014	8	Rectifier, Silicon	R15, R27	350-0435	. 2	Resistor (100,000-Ohm, 1/2 Watt)
CR12	359-0035	1	Diode, Zener (6.8 Volt)	R17	351-0524	1	Resistor, Metal Film
CR13	359-0025	1	Diode, Zener (20 Volt)				(13,000-Ohm, 1/4 Watt)
CR14	359-0026	1	Diode, Zener (18 Volt)	R18	303-0168	1	Potentiometer
CR15	359-0015	1	Diode, Zener (24 Volt)	R20, R22	351-0520	2	Resistor, Metal Film
K1	307-1063	1	Relay, Magnetic Reed	,	•••	_	(28,000-Ohm, 1/4 Watt)
Q1, Q2	362-0017	ż	Transistor, Silicon (NPN)	R21	351-0522	. 1	Resistor, Metal Film
Q3	361-0004	1	Transistor, Unijunction	7.44	••••	-	(5,110-Ohm, 1/4 Watt)
R1, R23	350-0355	2	Resistor (47-Ohm, 1/2 Watt)	R24	351-0523	1	Resistor, Metal Film
R2, R3	350-0351	2	Resistor (33-Ohm, 1/2 Watt)	116-7	00. 0020	•	(8,870-Ohm, 1/4 Watt)
R4	350-1075	- 1	Resistor (4.7 Megohm, 2 Watt)	R25	350-1011	1	Resistor (10,000-Ohm, 2 Watt)
R5	353-0040	1	Resistor, Fixed (270-Ohm,	R26	303-0164	i	Potentiometer
110	200 0040	•	10 Watt)	R28	350-0459	•	Resistor (1.0 Megohm, 1 Watt)
				nzo	550-0455	•	The state of the s

ENGINE CONTROL MONITOR GROUP (STANDARD SETS WITH ONE FAULT LIGHT)

12 VOLT




REF.	PART NO.	QTY. USED	PART DESCRIPTION
	300-0679	1	Monitor Assembly, Complete - Engine Control
K1	307-1039	1	Relay
R3	350-0548	1	Capacitor (10,000-Ohm)
C2.5	355-0005	2	Capacitor (22 Mfd.)
C3	356-0040	1	Capacitor (10 Mfd.)
C4	356-0030	1	Capacitor (1 Mfd.)
CR1	359-0027	1	Diode, Zener
CR2.3,4.5,7	357-0004	5	Rectifier, Diode
CR6	364-0017	1	Rectifier, Gate Control
Q1, Q4	361-0003	2	Transistor
Q2,3,5,6	362-0025	. 4	Transistor, Field Effect
Q7. Q8	362-0008	2	Transistor, Silicon
R1, R7	350-0536	2	Resistor (1000-Ohm)
R2	350-0526	1	Resistor (150-Ohm)
R6	350-0552	1	Resistor (22,000-Ohm)
R4. R10	303-0169	2	Potentiometer
R5	350-0572	1	Resistor (1 Megohm)
R8	350-0505	1	Resistor (2.7-Ohm)
R9	350-0517	1	Resistor (27-Ohm)
R11	350-0584	1	Resistor (10 Megohm)
R12,13,14	350-0529	3	Resistor (270-Ohm)
R15, R16	350-0540	2	Resistor (2.2-Ohm)
R17	350-1128	1	Resistor (220-Ohm)

CITY WATER COOLED WITH MARSH REGULATOR (UNHOUSED MODELS) INSTALLATION

179-0331

NOTE: REMOVE THERMOSTATS FROM ENGINE




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REI NO		PART NO.	QTY. USED	PART DESCRIPTION
1	503-0364	2	Hose, Radiator	22	 2 5	505-0131	1	Bushing, Reducer
2	503-0365	4	Clamps, Hose					(3/4 x 3/8")
3	505-0272	1	Nipple, Half (1-1/2 x 4")	23	3 5	604-0028	1	Cock, Drain
. 4	50 5-0317	2	Tee (1-1/2")	24	4 5	505-0102	1	Nipple, Close (3/4 x 1-3/8")
5	505-0424	1	Nipple (1-1/2 x 16-1/2")	25	5 1	30-0452	1	Fitting, Water Inlet
6	130-0488	1	Support, Pipe	26	6 5	503-0354	2	Clamps, Hose
7	800-0028	4	Screw, Hex Head Cap (5/16-18 x 1")	27	7		1	Hose, Order 3" of Bulk Hose #503-0357
8	862-0002	4	Nut, Hex (5/16-18")	28	8 5	503-0189	2 .	Clamps, Hose
9	850-0045	4	Lockwasher: (5/16")	29	9		1	Hose, Order 9-1/2" of
10	526-0115	4	Flat Washer (5/16")					Bulk Hose #503-0249
11	505-0289	1	Bushing, Reducer	30	0 5	505-0132	1	Elbow (3/4" x 90°)
*			(1-1/2 x 3/4")	3	1 3	307-0835	11	Valve, Solenoid
12	505-0474	1	Nipple, Half (1-1/2 x 5")	. 32		110-0810	1	Nipple & Bracket Assembly
13	309-0241	1	Valve, Temperature Control	3	3 5	505-0085	1	Nipple (3/4 x 2")
16	130-0499	1	Bracket, Support	. 3	-	321-0014	6	Screw, Lock Head
17	850-0040	2	Washer, Lock (1/4")	, ,				(5/16-18 x 1/2")
. 18	862-0001	2	Nut, Hex (1/4-20")	39	5 1	130-0454	1	*Guard, Belt
19	505-0166	1	Tee (3/4")	; 3i	•	130-0455	1	*Bracket, Guard Mounting
20	505-0324	ż	Nipple, Half (3/4 x 2")	i i	•	0	-	
21	800-0023	2	Screw, Hex Head Cap (1/4-20 x 1-3/8")	£. •	- N	lot shown i	n Illustration	on.

STANDPIPE WITH MARSH REGULATOR INSTALLATION 179-0302 NOTE: REMOVE THERMOSTATS **2**7-22

REF.	PART NO.	QTY. USED	PART DESCRIPTION
NO.			
1	130-0635	1	Standpipe
2	130-0454	1	Guard, Belt
3	130-0455	1	Bracket, Belt Guard
4	130-0636	1	Bracket, Standpipe Mounting
5	85 0-0050	4	Lockwasher (3/8")
6	800-0050	4	Screw, Hex Head Cap (3/8-16 x 1")
7	504-0028	2	Cock, Drain
8	505-0019	1	Bushing, Reducer (1/2 x 3/8")
9	505-0399	1	Bushing, Reducer (1-1/2 x 1/2")
10	505-0317	2	Tee (1-1/2")
11	505-0043	2	Elbow (1-1/2" x 90°)
12	505-0220	2	Nipple, Close (1-1/2 x 1-3/4")
13	130-0478	1	Fitting, Water Inlet
14	503-0354	2	Clamp, Hose
15	000 000	1	Hose - Order 3" of Bulk Hose #503-0357
16	505-0130	1	Plug, Square Head (3/4")
17	503-0332	2	Hose, Radiator - Upper
18	505-0261	2	Nippie (1-1/2 x 4-1/2")
19	505-0140	1	Plug, Square Head (1")
20	504-0062	1	Valve, Vacuum Relief
21	505-0444	. 4	Nipple, Half (1-1/2 x 2-1/4")
22	503-0365	6	Clamp, Hose
23		1	Hose - Order 7" of Bulk Hose #503-0411
24	505-0102	2	Nipple, Close (3/4")
25	309-0241	,1	Valve, Temperature Control, Water
26	307-0835	1	Valve
27	505-0289	1	Bushing, Reducer (1-1/2 x 3/4")

HEAT EXCHANGER INSTALLATION

179-0254



REF. NO.	PART NO.	OTY. USED	PART DESCRIPTION
1	130-0797	1	Bracket & Nipple Assembly
2	821-0014	6	Screw, Lock Head
			(5/16-18 × 1/2")
· з	307-1139	1	Valve, Solenoid
4	505-0089	2	Nipple, Half (1 x 5")
5	503-0004	2	Clamp, Hose
. 6		1	Hose - Order 12" of Bulk Hose #503-0361
7	130-0499	1	Bracket, Heat Exchanger
8	505-0004	2	Nipple, Close (1 x 1-1/2")
9	505-0140	1	Plug, Pipe (1")
10	130-0753	1	Exchanger, Heat
	800-0050	5	Screw, Hex Head Cap
• •			(3/8-16 x 1")
12	850-00 50	5	Lockwasher (3/8")
13	862-0003	5	Nut, Hex (3/8-16")
14	526-0029	4	Flatwasher (3/8")
15	800-0007	6	Screw, Hex Head Cap
40	250 2004	•	(1/4-20 x 1")
16	850-0004	6	Lockwasher (1/4")
. 17	862-0001	. 6	Nut, Hex (1/4-20")
18	503-0354	4 2	Clamp, Hose
19			Hose - Order 4" of Bulk Hose #503-0357
20	130-0478	2	Fitting, Water Inlet
21	5 05 - 0095	1	Nipple (1-1/2 x 12")
22	505-0043	1	Elbow (1-1/2")
23	130-0752	1	Bracket, Heat Exchanger
24	503-0311	2	Clamp, Hose
25	503-0332	2	Hose, Radiator
26	130-0454	1	Guard, Belt
27	130-0751	1	Brace
28	505-0385	2	Nipple Half (1-1/2 x 2")
29	505-0317	1	Tee (1-1/2")
30	505-0399	- 1	Bushing, Reducer (1-1/2 x 1/2")
31	504-0028	1	Drain Cock
32	505-0019	1	Bushing, Reducer (1/2 x 3/8")
33	503-0365	2	Clamp, Hose
34	232 0000	1	Hose - Order 4" of Bulk Hose #503-0411
36	505-0041	3	Elbow
37	505-0041	1	Nipple (1 x 2-1/2")
40	504-0090	i	Valve, Globe
42	505-0220	i	Nipple (1-1/2"), Close

HEAT EXCHANGER WITH MARSH REGULATOR INSTALLATION


NOTE: REMOVE THERMOSTATS FROM ENGINE 179-0296 (1)12(3)14 (IS (6) (7) **(E)** (B) (9) 25 11 12 13 24 (21) (23 θ 22 **@ 9 9 9**

REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	130-0797	1	Bracket & Nipple Assembly
3	307-1139	i	Valve, Solenoid
4	505-0089	2	Nipple, Half (1" x 5")
5	503-0004	2	Clamp, Hose
6	503-0361	1	Hose
8	505-0004	ż	Nipple, Close (1 x 1-1/2")
9	309-0242	1	Valve. Temperature Control -
_		•	Water
10	130-0753	1	Heat Exchanger
11	800-00 50	5	Hex Head Capscrew
			(3/8-16 x 1")
12	850-005 0	5	Lockwasher (3/8")
13	862-0003	5	Nut, Hex (3/8-16")
14	526-0029	4	Flatwasher (3/8")
15	800-0007	6	Screw, Hex Head Cap
			(1/4-20 x 1")
16	850-0004	6	Lockwasher (1/4")
17	862-0001	6	Nut, Hex (1/4-20")
18	503-0354	4	Clamp, Hose
19		2	Hose, Order 4" of Bulk
:			Hose #503-0357
20	130-0478	2	Fitting, Water Inlet
21.	505-0095	. 1	Nipple (1-1/2 x 12")
22	505-0043	. 1	Elbow (1-1/2")
23	130-0752	1	Bracket, Heat Exchanger
24	503-0311	2	Clamp, Hose
25	503-0332	2	Hose, Radiator (Cut to Size)
26	130-0454	1	Guard, Belt
27	130-0751	1	Brace
28.	505-0385	2	Nipple, Half (1-1/2 x 2")
29	505-0317	1	Tee (1-1/2")
30	505-0399	1	Bushing, Reducer
	*		(1-1/2 x 1/2")
31	504-0028	1	Drain Cock
32	505-0019	1	Bushing, Reducer (1/2 x 3/8")
33	503-0365	2	Clamp, Hose
34		1	Hose, Order 4" of Bulk
			Hose #503-0411
35	505-0129	1	Bushing, Reducer (1 x 3/4")
36	505-0041	3	Elbow
37	505-0086	1	Nipple (1 x 2-1/2")
39	505-0219	1	Nipple (1-1/4 x 4-1/2")
40	821-0014	6	Screw, Lock Head (5/16-18 x 1/2")
41	130-0499	1	Bracket, Heat Exchanger
42	505-0220	1	Nipple, Close (1-1/2")

CITY WATER COOLED WITH WATER COOLED EXHAUST MANIFOLD (HOUSED AND UNHOUSED MODELS) INSTALLATION - LATE MODELS

179-1008


NOTE: See separate groups for early models. Can be identified by exhaust manifolds. This installation has ONAN cast into the manifold.



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1		1	Hose, Order 23" of Bulk	33	130-0452	1	Fitting, Water Inlet
			Hose #503-0386	34	505-0131	1	Bushing, Reducer
. 2	800-0028	4	Screw, Hex Head Cap				(3/8 × 3/4")
è			(5/16-18 x 1")	35	504-0028	1 "	Cock, Drain
. 3	526-0115	4	Washer, Flat (5/16")	36	130-0499	1	Bracket, Heat Exchanger
: 4	850-004 5	4	Washer, Lock (5/16")	37	821-0014	6	Screw, Lock Head
. 5	862-0002	. 4	Nut, Hex (5/16-18")				(5/16-18 x 1/2")
6	154-1453	1	Manifold, Assembly (LH)	38	800-0007	2	Screw, Hex Head Cap
7	154-0592	2	Gasket Set, Manifold				(1/4-20 x 1")
, 8	813-0102	10	Screw, Hex Head Cap	39	850-0040	2	Washer, Lock (1/4")
g			(#10-32 x 5/8")	40	862-0001	2	Nut, Hex (1/4-20")
. 9	850 -0030	10	Washer, Lock (#10)	41	110-0526	1	Nipple & Bracket Assembly
10	870-0053	8	Nut, Hex (#10-32)	42	505-0474	1	Nipple, Half (1-1/2 x 5")
11	155-0660	2	Bracket, Exhaust Shield	43	505-0317	1	Tee (1-1/2")
	,		Mounting	44	130-0488	1	Support, Pipe
- 12	155-0661	2	Band, Shield Mounting	45	505-0424	1	Nipple (1-1/2 x 16-1/2")
13	15 5-1048	1	Tube Assembly, Exhaust	46	503-0364	2	Hose
14	155-06 15	1	Nipple, Half	47	505-0272	1	Nipple, Half (1-1/2 x 4")
15	505-0373	1	Tee, Reducer	48	503-0365	4	Clamp, Hose
			(2-1/2 x 2-1/2 x 3")	49		1	Hose, Order 11" of Bulk
16	505-0216	2	Elbow, Street (2-1/2")				Hose #503-0386
17	155-1047	1	Tube Assembly, Exhaust	50	505-0398	1	Tee, Side Outlet (1-1/2")
18		1	Hose, Order 38" of Bulk	51	504-0019	1	Valve, Lockshield
			Hose #503-0386	53	505-0108	1	Tee (1/2")
19	505-0399	4	Bushing, Reducer	54		1	Hose, Order 9" of Bulk
			(1-1/2 x 1/2")				Hose #503-0110
20	503-0189	6	Clamp, Hose	55	50 5- 0 010	2	Nipple, Half (1/4")
21	505-01 85	6	Nipple, Half (1/2 x 1-1/2")	56	503-0032	2	Clamp, Hose
22	505-0040	4	Elbow (1/2" x 90°)	57	505-0011	1	Elbow, Street (1/4")
23	505-0100	5	Nipple, Close (1/2")	58	505-0426	1	Bushing, Reducer
24	155-0659	2	Shield, Exhaust Header				(1-1/2 x 1/4")
25	520-0755	8	Stud (5-3/4 x 3/8-24")	59	505-0402	1	Plug (1-1/2")
26	520-0110	8	Stud (4-1/2 x 3/8-24")	60	505-0018	1	Bushing, Reducer
27	850-0050	16	Washer, Lock (3/8")				(1/2 x 1/4")
28	104-0091	16	Nut, Hex (3/8-24")	61	130-0454	1	*Guard, Belt
29	154-1452	1	Manifold Assembly (RH)	62	130-045 5	1	*Bracket, Guard Mounting
30	504-0005	2	Cock, Drain	63	800-0026	2	*Screw, Hex Head Cap
31		1	Hose, Order 3" of Bulk Hose #503-0357				(5/16-18 x 3/4") ~ Coil Mounting
; 32	503-0354	2	Clamp, Hose				

^{• -} Items not shown on Illustration.

179-0337 CITY WATER COOLED WITH WATER COOLED EXHAUST MANIFOLD (HOUSED MODELS) INSTALLATION - EARLY MODELS




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
2	504-0019	1	Valve, Lockshield	38	505-0474	· 1	Nipple, Half (1-1/2 x 5")
3	110-0526	1	Nipple & Bracket Assembly	39	505-0398	1	Tee, Side Outlet (1-1/2")
4	800-0007	2	Screw (1/4-20 x 1")	40	505-0272	7	Nipple, Half (1-1/2 x 4")
5	862-0001	2	Nut (1/4-20")	41	503-0365	4	Clamp, Hose
6	850-0040	2	Lockwasher (1/4")	42	503-0364	2	Hose
7	307-0833	1	Valve, Solenoid	43	145-0178	4	Gasket, Flange
8	505-0100	5	Nipple, Close (1/2")	44		1	Hose, Order 11" of Bulk
9	505-0040	4	Elbow (1/2" × 90°)				Hose #503-0386
10	505-0185	6	Nipple, Half (1/2 x 1-1/2")	45		1	Hose, Order 3" of Bulk
11	503-0189	6	Clamp, Hose				Hose #503-0357
12	*	1	Hose, Order 23" of Bulk	46	503-0354	2	Clamp, Hose
			Hose #503-0386	47	130-0452	1	Fitting, Water Inlet
13	130-0488	1	Support, Pipe	49	505-0131	1	Bushing (3/4 x 3/8")
14	800-0028	4	Screw (5/16-18 x 1")	50	504-0028	1	Cock, Drain
15	862-0002	8	Nut (5/16-18")	52	505-0108	1	Tee (1/2")
16	850-0045	10	Lockwasher (5/16")	53	505-0018	1	Bushing (1/2 x 1/4")
17	526-0115	4	Flatwasher (5/16")	54	505-0010	2	Nipple, Half (1/4")
18	505-0317	1	Tee (1-1/2")	55		1	Hose, Order 8" of Bulk
19	505-0402	1	Plug (1-1/2")				Hose #503-0110
21	800-0050	8	Screw (3/8-16 x 1")	56	503-0032	2	Clamp, Hose
22	850-0050	24	Lockwasher (3/8")	57	505-0011	1	Elbow, Street (1/4")
23	154-0611	4	Flange, Water Inlet	58	505-0426	1	Bushing (1-1/2 x 1/4")
24	154-1245	2	Manifold, Water Cooled	59	505-0424	1	Nipple (1-1/2 x 16-1/2")
25	870-0053	8	Nut (#10-32)	60	155-1048	1	Tube Assembly, Exhaust
26	813-0102	10	Screw (#10-32 x 5/8")	61	505-0057	2	Plug (1/8")
27	850-0030	10	Lockwasher (#10-32)	62	130-0454	1	Guard, Belt
28	155-0660	2	Bracket, Exhaust Shield	63	130-0455	1	Bracket, Guard Mounting
			Mounting	64	104-0091	16	Nut (3/8-24")
29	155-0661	2	Band, Shield Mounting	6 5	154-0592	2	Gasket Sets, Manifold
30	155-0659	2	Shield - Exhaust Header	66	800-0026	2	Screw, Coil Mounting
31	505-0373	1	Tee, Reducer				(5/16-18 x 3/4")
32	155-0615	1	(2-1/2 x 2-1/2 x 3") Nipple, Half	69	800-0026	4	Screw, Hex Head Cap (5/16-18 x 3/4")
33	155-1047	i	Tube Assembly, Exhaust	70	130-0828	1	Bracket, Support
33 34	505-0216	2	Elbow, Street (2-1/2")	70	100-0020	•	Diagnot, Support
35	303-0210	1	Hose, Order 38" of Bulk	NOTE	See senarat	e aroup fo	r late models. Can be identified
55		,	Hose #503-0386	1.072	by exhaust	manifolds	This installation does not have
36	504-0005	2	Cock, Drain	Ł	ONAN cast into the manifolds.		

CITY WATER COOLED WITH WATER COOLED EXHAUST AND MARSH REGULATOR (HOUSED AND UNHOUSED MODELS) INSTALLATION - LATE MODELS


179-1007

NOTE: See separate groups for early models. Can be identified by exhaust manifolds. This installation has ONAN cast on the manifolds.




REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1 1		1	Hose, Order 23" of Bulk	29	154-1452	1	Manifold Assembly (RH)
:			Hose #503-0386	30	504-0005	2	Cock, Drain
2	80 0-0028	4	Screw, Hex Head Cap (5/16-18 x 1")	31	00.000	1	Hose, Order 3" of Bulk Hose #503-0357
. 3	526-0115	4	Washer, Flat (5/16")	32	503-0354	2	Clamp, Hose
4	85 0-0045	4	Washer, Lock (5/16")	33	130-0452	1	Fitting, Water Inlet
5	862-0002	4	Nut, Hex (5/16-18")	34	505-0131	i	Bushing, Reducer (3/8 x 3/4")
6	154-1453	1	Manifold Assembly (LH)	35	504-0028	1	Cock, Drain
7	154-0592	2	Gasket Set, Manifold	36	130-0499	<u> i</u>	Bracket, Heat Exchanger
8	813-0102	10	Screw, Hex Head Cap	37	821-0014	6	Screw, Lock Head
i g	850-0030	10	Washer, Lock (#10)	•	02. 00	_	(5/16-18 x 1/2")
10	870-0053	8	Nut, Hex (#10-32)	38	800-0007	2	Screw, Hex Head Cap
11	155-0660	2	Bracket, Exhaust Shield	•		_	(1/4-20 x 1")
		-	Mounting	:39	850-0040	2	Washer, Lock (1/4")
; 12	155-0661	2	Band, Shield Mounting	40	862-0001	2	Nut, Hex (1/4-20")
13	155-1048	1	Tube Assembly, Exhaust	41	110-0526	1	Nipple & Bracket Assembly
1 14	155-0615	2	Nipple, Half	42	505-0474	1	Nipple Half (1-1/2 x 5")
15	505-0373	1	Tee, Reducer	43	505-0317	2	Tee (1-1/2")
, ,,	•••		(2-1/2 x 2-1/2 x 3")	44	130-0488	1	Support, Pipe
16	505-0216	2	Elbow, Street (2-1/2")	45	505-0424	1	Nipple (1-1/2 x 16-1/2")
17	155-1047	1	Tube Assembly, Exhaust	46	503-0364	2	Hose
18		1	Hose, Order 38" of Bulk	47	505-0272	. 1	Nipple, Half (1-1/2 x 4")
			Hose #503-0386	48	503-0365	4	Clamp, Hose
19	505-0399	4	Bushing, Reducer (1-1/2 x 1/2")	51		1	Hose, Order 11" of Bulk Hose #503-0386
. 20	503-0189	6	Clamp, Hose	53	307-0833	1	Valve, Solenoid
21	505-0185	6	Nipple, Half (1/2 x 1-1/2")	. 55	505-0021	2	Bushing, Reducer (3/4 x 1/2")
22	505-0040	4	Elbow (1/2" x 90°)	56	309-0241	1	Valve, Water Temperature
; 23	505-0100	5	Nipple, Close (1/2")	-	200 02 / /	•	Control
24	155-0659	2	Shield, Exhaust Header	57	800-0026	2	*Screw, Hex Head Cap
25	520-0755	8	Stud (5-3/4 x 3/8-24")	O,		_	(5/16-18 x 3/4")
26	520-0110	8	Stud (4-1/2 x 3/8-24")				Coil Mounting
27	850-0050	16	Washer, Lock (3/8")				
28	104-0091	16	Nut, Hex (3/8-24")	• _	Item not sho	wn on Illu	stration.

CITY WATER COOLED WITH WATER COOLED EXHAUST MANIFOLD AND MARSH REGULATOR (HOUSED MODELS) INSTALLATION




REF.	PART NO.	QTY. USED	PART DESCRIPTION		EF.	PART NO.	QTY. USED	PART DESCRIPTION
1	130-0828	1	Bracket, Support		32	155-0615	1	Nipple, Half
2	309-0241	1	Valve, Water Temperature		33	155-1047	1	Tube Assembly, Exhaust
			Control	•	34	505-0216	2	Elbow, Street (2-1/2")
3	110-0526	1	Nipple & Bracket Assembly	,	35		1	Hose, Order 38" of Bulk
4	800-0007	2	Screw (1/4-20 x 1")	3				Hose #503-0386
5	862-0001	2	Nut (1/4-20")		36	504-00 05	2	Cock, Drain
6	850-0 040	2	Lockwasher (1/4")		37	505-0132	1	Elbow (3/4" x 90°)
7	307-083 3	1	Valve, Solenoid		38	505-0474	1	Nipple, Half (1-1/2 x 5")
8	505-0100	5	Nipple, Close (1/2")		40	505- 0272	1	Nipple, Half (1-1/2 x 4")
9	505-0040	4	Elbow (1/2" x 90°)		41	503-036 5	4	Clamp, Hose
10	505- 0185	6	Nipple, Half (1/2 x 1-1/2")		42	503-0364	2	Hose
11	503-0189	6	Clamp, Hose		43	145-0178	4	Gasket, Flange
12		1	Hose, Order 23" of Bulk Hose #503-0386		44		1	Hose, Order 20" of Bulk Hose #503-0386
13	130-0488	1	Support, Pipe		45		1	Hose, Order 3" of Bulk
14	800-0028	4	Screw (5/16-18 x 1")					Hose #503-0357
15	862-0002	8	Nut (5/16-18")		46	50 3-0354	2	Clamp, Hose
. 16	850-0 045	10	Lockwasher (5/16")		47	130-0452	1	Fitting, Water Inlet
17	526-0115	4	Flatwasher (5/16")		48	50 5-0166	1	Tee (3/4")
18	505-0317	2	Tee (1-1/2")		49	505-013 1	· 1	Bushing (3/4 x 3/8")
k 19	505~0289	1	Bushing, Reducer		50	504-0028	1	Cock, Drain
Ï			(1-1/2 × 3/4")		51	505-0084	1	Nipple (3/4 x 2-1/2")
20	505~0021	2	Bushing (3/4 x 1/2")		59	505-0424	1	Nipple (1-1/2 x 16-1/2")
21	800-0050	8	Screw (3/8-16 x 1")		60	155-1048	1	Tube Assembly, Exhaust
22	850-0050	24	Lockwasher (3/8")		61	505-0 057	2	Plug (1/8")
· 23	154-0611	4	Flange, Water Inlet		62	130-0454	1	Guard, Belt
24	154-1245	2	Manifold, Water Cooled		63	130-0455	1	Bracket, Guard Mounting
25	870~0053	8	Nut (#10-32)		64	104-0091	16	Nut (3/8-24")
26	813-0102	10	Screw (#10-32 x 5/8")		6 5	154-0592	2	Gasket Set, Manifold
27	850-0030	10	Lockwasher (#10)		66	800-0026	6	Screw, Coil Mounting
28	155-0660	2	Bracket, Exhaust Shield					(5/16-18 × 3/4")
			Mounting		67	505-0102	٠ 1	Nipple, Close (3/4")
29	155-0661	2	Band, Shield Mounting		•	·- -		
30	155-0659	2	Shield, Exhaust Header					
31	505-0373	1	Tee, Reducer					
:			10 1/0 0 0 1/0 0 2/1					

CITY WATER COOLED (UNHOUSED MODELS) INSTALLATION




REF.	PART NO.	QTY. USED	PART DESCRIPTION		EF.	PART NO.	QTY. USED	PART DESCRIPTION
. 1	505-0402	1	Plug, Square Head	:	22	505-0085	1	Nipple, Pipe (3/4 x 2")
. 2	505-0317	1	Tee, Pipe (1-1/2")	2	23	130-0452	1	Fitting, Water Inlet
3	505-0474	1	Nipple, Half (1-1/2 x 5")	:	24	505-0166	1	Tee, Pipe (3/4")
4	503-0364	2	Hose, Radiator		25	505-0131	1	Bushing, Reducer
5	503-0365	4	Clamp, Hose					(3/4 x 3/8")
6	505-0398	1	Tee, Side Outlet (1-1/2")	:	26	504-0028	1	Cock, Drain
7	505-0272	1	Nipple, Half (1-1/2 x 4")	:	27	505-0324	2	Nipple, Half (3/4 x 2")
8	800-0028	4	Screw, Hex Head Cap (5/16-18 x 1")	:	28		1	Hose - Order 8" of Bulk Hose #503-0249
' 9	862-0002	4	Nut, Hex (5/16-18")	:	29	503-0189	2	Clamp, Hose
10	850-0045	4	Washer, Lock (5/16")		30	505-0132	1	Elbow, Pipe (3/4 x 90°)
11	526-0115	4	Washer, Flat (5/16")		31	800-0023	2	Screw, Hex Head Cap
. 12	130-0488	1	Clamp, Pipe					(1/4-20 x 1-3/8")
. 13	505-0424	1	Nipple, Pipe	;	32	862-0001	2	Nut, Hex (1/4-20")
			(1-1/2 x 16-1/2")	:	33	850-0040	2	Washer, Lock (1/4")
14	505-0011	1	Elbow, Street (1/4")		34	821-0014	8	Screw, Lock Head
15	505-0010	2	Nipple, Half (1/4 x 1")		-			(5/16 x 2")
· 16	505-0426	1	Bushing, Reducer	;	35	130-0499	1	Bracket, Heat Exchanger
•			(1-1/2 x 1/4")		36	504-0046	1	Valve, Globe
ž 17	503-0032	2	Clamp, Hose		38	110-0810	1	Bracket & Nipple
- 18	503-0032	1	Hose - Order 16-1/4" of		39	307-0835	1	Valve, Solenoid
ş			Bulk Hose #503-0110		40	505-0102	1	Nipple, Close (3/4")
⁻ 19	505-0018	1	Bushing, Reducer		41	130-0454	1	*Guard, Belt
		**	(1/2 x 1/4")		42	130-0455	1	*Bracket, Belt Guard
20		7	Hose - Order 3" of Bulk	ţ.	-		-	
¥			Hose #503-0357	\$	• _	Not shown in	Illustratio	n.
21	_503-0354	2	Clamp, Hose	•				

CITY WATER COOLED (HOUSED MODELS) INSTALLATION




PREF.	PART NO.	QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	USED	PART DESCRIPTION
1	50 5-0402	1	Plug, Square Head	19	505-0018	1	Bushing, Reducer
2	505-0317	1	Tee, Pipe (1-1/2")				(1/2 x 1/4")
3	505-0474	1	Nipple, Half (1-1/2 x 5")	20		1	Hose, Order 3" of Bulk
4	503-0364	2	Hose, Radiator				Hose #503-0357
5	503-0365	4	Clamp, Hose	21	503-0354	2	Clamp, Hose
6	505-0398	1	Tee, Side Outlet (1-1/2")	22	504-0028	1	Cock, Drain
7	505-03 85	1	Nipple, Half (1-1/2 x 2")	23	130-0452	1	Fitting, Water Inlet
8	800-0028	4	Screw, Hex Head Cap	24	505-0166	1	Tee, Pipe (3/4")
			(5/16-18 x 1")	25	505-0131	1	Bushing, Reducer
9	862-0002	4	Nut, Hex (5/16-18")				(3/4 x 3/8")
10	850-0045	4	Washer, Lock (5/16")	26	505-0102	2	Nipple, Close (3/4")
11	526-0115	4	Washer, Flat (5/16")	27	130-0528	1	Support, Pipe
12	130-0488	1	Clamp, Pipe	28	130-082 8	1	Bracket, Support
13	505-0424	1	Nipple, Pipe	29	505-0084	2	Nipple (3/4 x 2-1/2")
			(1-1/2 x 16-1/2")	30	505-0132	1	Elbow, 90° (3/4")
14	505-0011	1	Elbow, Street (1/4")	31	800-0023	2	Screw, Hex Head Cap
15	505-0010	2	Nipple, Half (1/4 x 1")				(1/4-20 x 1-3/8")
16	505-0426	1	Bushing, Reducer	32	862-0001	2	Nut, Hex (1/4-20")
			(1-1/2 x 1/4")	33	850-0040	2	Washer, Lock (1/4")
17	503-0032	2	Clamp, Hose	36	504-0046	1	Valve, Globe
18		1	Hose, Order 16-1/4" of	38	110-0810	1	Bracket & Nipple
			Bulk Hose #503-0110	. 39	307-0835	1	Valve, Solenoid



WATER COOLED EXHAUST MANIFOLD (RADIATOR COOLED) **INSTALLATION - LATE MODELS**

179-1006


NOTE: See separate group for early models. Can be identified by exhaust manifolds. This installation has ONAN cast into the manifolds.



	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
:-	1	504-0028	1	Cock, Drain	20	503-0189	8	Clamp, Hose
:	2	154-1453	1	Manifold Assembly (LH)	21	148-0274	1	Clamp, Hose
•	3	870-0053	8	Nut, Hex (#10-32)	22		1	Hose, Order 30" of Bulk
;	4	813-0102	8	Screw, Round Head Mounting				Hose #503-0191
*	•	0.00.0	_	(#10-32 x 5/8")	23	505-0019	1	Bushing, Reducer (1/2 x 3/8")
	5	850-0030	8	Washer, Lock (#10)	24	505-0248	1	Elbow, Street (45° x 1/2")
è	6	155-1048	. 1	Tube, Exhaust Assembly	25	505-0100	8	Nipple, Close (1/2")
5	7	155-0661	2	Band, Shield Mounting	26	503-0191	1	Hose (13-1/2")
1	8	155-0660	2	Bracket, Exhaust Shield	27	505-0216	2	Elbow, Street (2-1/2")
i	•			Mounting	28	520-0110	8	Stud (3/8-24 x 4-1/2")
3	9		2	Hose, Order 8" of Bulk	29	520-0755	8	Stud (3/8-24 x 5-1/2")
	_			Hose #503-0191	30	850-0050	16	Washer, Lock (3/8")
	10	155-0615	1	Nipple, Exhaust Tube	31	104-0091	16	Nut, Hex (3/8-24")
	11	505-0373	1	Tee, Reducing	32	155-0659	2	Shield, Exhaust Header
	• •			(2-1/2 x 2-1/2 x 3")	33	154-0592	2	Gasket Set, Manifold
٠	12	155-1047	1	Tube, Exhaust Assembly	34	800-0026	2	*Screw, Hex Head Cap
	13	130-0745	1	Water Line, Manifold Drain				(5/16-18 x 3/4")
	14	505-0185	8	Nipple, Half (1/2")				Coil Mounting
Î	15	505-0040	5	Elbow (1/2" x 90°)	35	850-0045	2	*Washer, Lock (5/16")
;	16	505-0399	4	Bushing, Reducer				Coil Mounting
		•••		(1-1/2 x 1/2")	36	505-0185	1	Nipple, Half (1/2" x 1-1/2")
	17	154-1452	1	Manifold Assembly (RH)	37	503-0191	6	Hose, Rubber (3/4 x 1-1/8")
į	18	504-0005	2	Cock, Drain				
	19	505-0108	3	Tee (1/2")	1	Not shown i	n Illustrati	on.


	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
	1	130-0635	1	Standpipe
	2	130-0454	1	Guard, Belt
ı	2 3	130-0455	1	Bracket, Belt Guard
- [4	130-0636	1	Bracket, Standpipe Mounting
- [5	850-0050	4	Lockwasher (3/8")
1	6	800-0050	4	Screw, Hex Head Cap (3/8-16 x 1")
Ì	7	504-0028	1	Cock, Drain
Ī	11	505-0043	4	Elbow (1-1/2" x 90°)
	12	505-0220	2	Nipple, Close (1-1/2 x 1-3/4")
ŧ	13	130-0478	1	Fitting, Water Inlet
İ	14	503-0354	2	Clamp, Hose
ļ	15		, 1	Hose - Order 3" of Bulk Hose #503-0357
	16	505-0130	1	Plug, Square Head (3/4")
	17	503-0332	ż	Hose, Radiator Upper
	18	505-0261	2	Nipple (1-1/2 x 4-1/2")
	19	505-0140	1	Plug, Square Head (1")
	20	504-0062	. i	Valve, Vacuum Relief
:	21	505-0444	4	Nipple, Half (1-1/2 x 2-1/4")
	22	503-0365	6	Clamp, Hose
	23		1	Hose - Order 7" of Bulk Hose #503-0411
	24	505-0102	2	Nipple, Close (3/4")
	26	307-0835	1	Valve
	27	504-0046	1	Vaive, Lockshield

WATER JACKET HEATER (120 VOLTS) INSTALLATION




REF.	PART NO.	QTY. USED	PART DESCRIPTION
. 1	309-0106	1	Thermostat
2	333-0012	1	Box, Thermostat
3	333-0013	. 1	Cover, Thermostat Box
4	333-0052	1	Heater
5	503-0183	1	Clamp, Hose
6	503-0131	3	Clamp, Hose
8	505-0135	1	Nipple, Half (3/8 x 1-1/2")
. 9	520-0446	2	Stud
10	870-0053	2	Nut, Hex (#10-32)
11	850-0030	2	Lockwasher (#10)
12		1	Hose - Order 12" of Bulk Hose #503-0386
13		1	Hose - Order 11" of Bulk Hose #503-0386
14	505-0019	1	Bushing, Reducer (1/2 x 3/8")
16	505-0101	1	Nipple, Close (1/4")
17	505-0184	- 1	Tee (1/4")
18	504-0003	1	Valve, Drain
19	130-0755	1	Bracket

WATER JACKET HEATER (240 VOLTS) INSTALLATION



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	309-0256	1	Thermostat
2	333-0057	1	Box, Thermostat
3	333-0056	1	Cover, Thermostat Box
4	333-0073	1	Heater
5	503-0183	1	Clamp, Hose
6	503-0131	3	Clamp, Hose
7	505-0119	1	Elbow, Stud (3/8" x 45°)
8	505-0135	1	Nipple, Half (3/8 x 1-1/2")
9	332-0672	2	Stud
10	870-0053	2	Hex Nut (#10-32)
11		2	Lockwasher (#10)
12		1	Hose, Order 8" of Bulk Hose #503-0386
13		1	Hose, Order 11" of Bulk Hose #503-0386
14	505-0019	1	Bushing, Reducer (1/2 x 3/8")
16	505-0101	1	Nipple, Close (1/4")
17	505-0184	1	Tee (1/4")
18		1	Valve, Drain
19	130-0755	. 1	Bracket


OPTIONAL HYDRAULIC GOVERNOR INSTALLATION



RE	F. O.	PART NO.	QTY. USED	PART DESCRIPTION
:	1	145-0375	1	Link, Throttle Lever Extension
	2	800-0003	2	Screw, Hex Head Cap (1/4-20 x 1/2")
,	3	850-004 0	4	Lockwasher (1/4")
	4	862-0001	2	Nut, Hex (1/4-20")
	5	150-1036	2 2 4	Joint, Governor Ball
	6	115-0025	4	Nut, Hex (1/4-28")
	7	520-05 15	1	Stud, Governor Control
	8	151-0332	1	Arm, Governor Spring Mounting
	9	150-0698	1	Spring, Governor
	0	151-0325	1	Bracket, Governor Spring Mounting
1	1	151-0331	1	Arm, Governor
	2	800-0031	2	Screw, Hex Head Cap (5/16-18 x 1-1/2")
1	3	145-0441	1	Body, Throttle
1	6	850-0045	2	Lockwasher (5/16")
	7		2 2	Nut, Hex (5/16-18")
	8	502-0246	1	Elbow, 3/8" Inverted 1/8" Pipe
- 2	20	151-0296	1	Drive Kit, Governor
	21	151-0299	1	Spacer, Drive
2	22	151-0300	1	Coupling, Drive
	23	151-03 19	1	Governor, Hydraulic
2	24	812-015 5	1	Screw, Round Head Machine (1/4-20 x 1-1/4")
	25	502-0106	1	*Connector, 3/8" Inverted 1/8" Pipe
2	26	504-0077	1	*Valve, Check
	27	120-0654	1	*Line, Oil

^{* -} Not shown in Illustration.

OPTIONAL NATURAL GAS AND LPG VAPOR (AUTOMATIC CHANGEOVER) INSTALLATION



REF.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
	140-0851		Air Cleaner	17	148-0626	1	*Valve, Adjustment
. 2	148-0592	i	*Carburetor (Impco #200 with				(Impco #AB1-32 - 1")
; 2	140-0002	•	1-3/4" Flange & 3-1/16"	18	505-0041	1	Elbow (1 x 90°), Pipe
			Air Hose)	19	148-0620	1	Collar, Shaft
3	505-0102	2	Nipple, Close (3/4")	20	850-0055	2	Washer (7/16), Lock
. 4	505-0102	2	Bushing, Reducer (1 x 3/4")	21	800-0071	2	Screw (7/16-14 x 1"),
- 1	505-0129	5	Nipple, Close (1")				Hex Head Cap
5	505-0004	1	Tee (1"), Pipe	22	145-0358	1	Adapter, Carburetor
, 6	148-0601		*Valve, Pressure Reduction	23	145-0410	1	Body Assembly, Throttle
i /	148-0001	•	(Impco #T-30)	24	145-0185	2	Gasket
	EOE 0003	•	Bushing, Reducer	25	150-0638	2	Joint, Ball
, 8	505-0023	•	(1-1/4 x 1")	26	850-0040	1	Washer (1/4"), Lock
, ,	EOE 0042	2	Elbow (1-1/4 x 90°), Pipe	27	115-0025	4	Nut (1/4-28), Hex
, 9	505-0042 505-0258	1	Nipple (1-1/4 x 3"), Pipe	28	520-0517	1	Stud
10	331-0101	,	Hanger (1-1/4")	29	191-0101	1	Strap, Generator Adjusting
111	307-0837	;	Valve, Solenoid	30	505-0249	1	Tee (1-1/4")
12	· · · ·	2	Nipple, Close (1-1/4")	31	505-0766	1	Bushing, Reducer
13	505-0177	1	*Switch, Pressure	٠,	000 0.00		(1-1/4 x 1")
14	148-0627	•	(Impco #AP-153-R33)	32	505-0099	1	Nipple, Close (1/4")
15	307-0312	1	Valve, Magnetic				
16	148-0636	. 1	*Valve, Pressure Reduction (Impco #T-30 Less	or	r component Impco Divisi	on, 16916	your nearest Impco dealer Gridley Place, Cerritos,

28

27


27,25

27

or Impco Division, 16916 Gridley Place, Cerritos, California 90701


Pressure Spring)

OPTIONAL NATURAL GAS AND LPG LIQUID (MANUAL CHANGEOVER) INSTALLATION



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	148-0728	1	Carburetor and Valve Assembly	25		1	Hose, Order 42" of Bulk Hose #503-0386
2	503-0324	2	Nipple, Half (3/4" x 2")	26	505-0019	1	Bushing, Reducer
3	50 5-0102	1	Nipple, Close (3/4")		-		(1/2 x 3/8")
8	503-0189	· 4	Clamp, Hose	27	505-0356	1	Elbow, Reducer (1 x 3/4")
9	505-0135	3	Nipple (3/8 x 1/2"), Half	28	504-0005	1	Cock, Drain (1/8")
10	505-0039	2	Elbow (3/8"), Pipe	29	505-0084	1	Nipple (3/4 x 2-1/2"),
11	50 5-0101	3	Nipple, Close (3/8")				Pipe
12	504-0028	1	Cock, Drain (3/8")	30	503-0249	1	Hose (3/4" x 8-3/4")
13	505-0060	1	Tee, Pipe (3/8")	32	148-0274	1	Bracket, Hose .
17	505-0132	2	Elbow (3/4"), Pipe	33	131-0192	1	Line, Water
19	307-0268	1	Valve, Solenoid	34	505-0021	. 1	Bushing, Reducer
20	800-0009	2	Screw, Hex Head Cap				(3/4 x 1/2")
			(1/4-20 x 1-1/2")	35	502-0227	1	Connector, Inverted Male
21	850-0040	2	Washer (1/4"), Lock	. 36	505-0071	1	Nipple (3/4 x 2"), Pipe
22	862-0001	2	Nut (1/4-20), Hex	37	505-0107	1	Nipple, Short (1 x 2")
23	148-0625	1	*Converter Assembly, Gas (Impco Model EB)	* - Fo	r component	s contact y	our nearest impco dealer
24	148-0631	1	Bracket, Vaporizer	or & C 8	Impco Divisi Jifornia 9070	on, 16916 (1.	Gridley Place, Čerritos,


OPTIONAL CARBURETOR AND REGULATOR ASSEMBLY (NATURAL GAS AND LPG — MANUAL CHANGEOVER)



REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	148-0592	1	*Carburetor (Impco #200 with 1-3/4" Flange and 3/16" Air Horn)
2	148-0601	1	*Valve, Thermal (Impco #T-30)
3	505-0102	1	Nipple, Close (3/4 x 1-3/8")
4	505-0129	1	Bushing, Reducer (1 x 3/4")
5	800-0071	2	Screw, Hex Head (7/16-14 x 1")
6	145-0358	1	Adapter, Carburetor
7	145-0328	1	Body Assembly, Throttle
8	150-0638	2	Joint, Ball
9	115-0025	4	Nut, Hex (1/4-28")
10	850-0040	1	Washer, Lock (1/4")
11	520-0629	1	Stud
13	148-0620	1	Collar, Shaft
14	850-0055	2	Washer, Lock (7/16")
15	145-0185	2	Gasket

For components contact your nearest Impco dealer or Impco Division, 16916 Gridley Place, Cerritos, California 90701.


OPTIONAL CARBURETOR AND REGULATOR ASSEMBLY GROUP (NATURAL GAS — GASOLINE)



REF.	PART NO.	QTY. USED	PART DESCRIPTION
1	145-0396	1	Adapter, Carburetor
2	503-05 50	1	Adapter, Hose
3	503-0354	2	Clamp
4		1	Gasket (Supplied with Mixer) - Impco #G7-21
5		4	Screw (Supplied with Mixer) - Impco #51-19
6	148-0598	1	*Carburetor Mixer - (Impco #200 with 3-1/16" Air Hom)
7	505-0102	1	Nipple (3/4 x 1-3/8")
В	505-0129	1	Bushing, Reducer (1 x 3/4")
9	148-0601	1	*Regulator - Natural Gas (Impco #T-30)

For components contact your nearest Impco dealer or Impco Division, 16916 Gridley Place, Cerritos, California 90701.


OPTIONAL CARBURETOR AND REGULATOR ASSEMBLY (LPG VAPOR)



REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	148-0636	1	*Regulator, Natural Gas (Impco #T-30 Less Pressure Spring)
2	505-0129	1	Bushing, Reducing (3/4 x 1")
3	505-0102	2	Nipple, Close (3/4 x 1-3/8")
4	307-0312	1	Valve, Magnetic (3/4")
5	148-0592	1	*Carburetor - Natural Gas (Impco #200 with 1-3/4" Flange & 3-1/16" Air Horn)
6	800-0071	2	Screw, Hex Head Cap (7/16-14")
7	850-0055	2	Washer, Lock (7/16")
8	110-0445	4	Nut, Hex Head Cap (5/16-24")
9	850-0045	4	Washer, Lock (5/16")
10	145-0358	1	Adapter, Carburetor
11	145-0185	2	Gasket, Carburetor Flange
12	115-0025	4	Nut, Hex Head Cap (1/4-28")
13	850-0040	1	Washer, Lock (1/4")
14	520-0517	1	Stud (1/4-28 x 7")
15	145-0410	1	Body Assembly, Throttle
16	150-0638	2	Joint, Ball (1/4-28")


For components contact your nearest Impco dealer or Impco Division, 16916 Gridley Place, Cerritos, California 90701.

OPTIONAL CARBURETOR AND CONVERTER ASSEMBLY (GASOLINE - LPG LIQUID)



REF.		QTY. USED	PART DESCRIPTION	REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	307-0268	1	Valve, Solenoid	16		1	Carburetor Regulator Assembly
2	505-0101	3	Nipple, Pipe (3/8 x 1")				- LPG - See Optional
3	505-0039	2	Elbow, Pipe (3/8")				Carburetor Assembly
4	504-0028	1	Cock, Drain (3/8")				(Gasoline-LPG Liquid)
5	505-0060	1	Tee, Pipe (3/8")	17	505-0019	1	Bushing, Reducer (1/2 x 3/8")
k 6	505-0135	3	Nipple, Half (3/8")	18	505-0107	1	Nipple, Short (1 x 2")
7	503-0189	4	Clamp, Hose	19	505-0356	1	Elbow, Reducer (1 x 3/4")
7 8	•••	1	Hose, Order 42" of Bulk	20	504-0005	1	Cock, Drain
£ _			Hose #503-0386	21	505-0324	1	Nipple, Half (3/4 x 2")
F 9	131-0192	1	Line, Water	22	503-0382	2	Clamp, Hose
- 10	148-0274	1	Clamp, Loop Type	23		1	Hose, Order 12" of Bulk
5511	502-0227	i	Connector, Inverted Male				Hose #503-0249
-12	505-0021	1	Bushing, Reducer (3/4 x 1/2")	24	148-0631	1	Bracket, Vaporizer
1 13	505-0132	1	Elbow, Pipe (3/4")				
	505-0071	1	Nipple, Pipe (3/4 x 1-1/4")	* - Fo	r components	contact y	our nearest Impco dealer
14	148-0625	i	*Converter Assembly, Gas	or	Impco Divisio	n. 16916 (Gridley Place, Cerritos,
L.			(Impco Model EB)		lifornia 90701		•

OPTIONAL CARBURETOR ASSEMBLY (GASOLINE - LPG LIQUID)




REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	145-0396	1	Adapter, Carburetor
2	503-0550	1	Adapter, Hose
3	503-0354	2	Clamp
4		1	Gasket (Supplied with Mixer - Impco #G1-21)
5		4	Screw (Supplied with Mixer - Impco #51-14)
6	148-0598	1	*Carburetor Mixer (Impco #200 with 3-1/16" Air Horn)
7	505-0102	1	Nipple (3/4 x 1-3/8")
8	505-0132	1	Elbow (3/4" x 90°)
9	505-0324	1	Nipple, Half (3/4 x 2")

For components contact your nearest Impco dealer or Impco Division, 16916 Gridley Place, Cerritos, California 90701.

OPTIONAL CARBURETOR AND CONVERTER ASSEMBLY (LPG LIQUID)

148-0694




NO.	PART NO.	QTY. USED	PART DESCRIPTION	REF.		QTY. USED	PART DESCRIPTION
1	307-0268	1	Valve, Solenoid	16		1	Carburetor and Regulator
2	505-0101	3	Nipple, Pipe (3/8 x 1")	,0			Solenoid Assembly, LPG (See
3	505-0039	2	Elbow, Pipe (3/8")				Optional Carburetor Assembly -
4	504-0028	1	Cock, Drain (3/8")				LPG Liquid)
5	505-0060	1	Tee, Pipe (3/8")	17	505-0019	1	Bushing, Reducer (1/2 x 3/8")
6	505-013 5	3	Nipple, Half (3/8")	18	505-0107	i	Nipple, Short (1 x 2")
7	503-0189-	4	Clamp, Hose	19	505-0356	1	Elbow, Reducer (1 x 3/4")
. 8		1	Hose, Order 42" of Bulk	20	504-0005	1	Cock, Drain
<u>}</u>			Hose #503-0386	21	505-0324	1	Nipple, Half (3/4 x 2")
9	131-0192	1	Line, Water	22	503-0382	2	Clamp, Hose
10	148-0274	1	Clamp, Loop Type	23	•••	1	Hose, Order 12" of Bulk
11	502-0227	1	Connector, Inverted Male	20			Hose #503-0249
12	505-0021	1	Bushing, Reducer (3/4 x 1/2")	24	148-0631	1	Bracket, Vaporizer
13	505-0040	1	Elbow, Pipe (1/2")	• Fo	r components	contact v	our nearest Impco dealer
14	505-0106	1	Nipple, Pipe (1/2 x 1-1/2")	or	Impco Divisio	on. 16916 (Sridley Place, Cerritos,
15	148-0625	1	*Converter Assembly, Gas		difornia 90701		

(Impco Model EB)

OPTIONAL CARBURETOR AND REGULATOR ASSEMBLY (LPG LIQUID)






REF. NO.	PART NO.	QTY. USED	PART DESCRIPTION
1	505-0132	1	Elbow (3/4")
2	505-0324	1	Nipple, Half (3/4 x 2")
3	505-0102	2	Nipple, Close (3/4 x 1-3/8")
4	307-0312	1	Valve, Magnetic (3/4")
5	148-0592	1	*Carburetor, Natural Gas (Impco #200)
6	800-0071	2	Screw, Hex Head Cap (7/16-14")
7	850-0055	2	Washer, Lock (7/16")
8	110-0445	4	Nut, Hex Head Cap (5/16-24")
9	850-0045	4	Washer, Lock (5/16")
10	145-0358	1	Adapter, Carburetor
11	145-0185	2	Gasket, Carburetor Flange
12	115-0025	4	Nut, Hex Head Cap (1/4-28")
13	850-0040	1	Washer, Lock (1/4")
14	520-0517	1	Stud (1/4-28 x 9-7/8")
15	145-0410	1	Body Assembly, Throttle
16	150-0638	2	Joint, Ball (1/4-28")

For components contact your nearest Impco dealer or Impco Division, 16916 Gridley Place, Cerritos, California 90701.

OPTIONAL CARBURETOR ASSEMBLY (NATURAL GAS)




•	REF.	PART NO.	QTY. USED	PART DESCRIPTION
	- 1	148-0592	1	*Carburetor (Impco #200)
	2	148-0601	1	*Valve, Thermal (Impco #T-30)
	3	505-0102	1	Nipple, Close (3/4 x 1-3/8")
	~ 4	505-0129	1	Bushing, Reducer
	5	800-0071	2	Screw, Hex Head Cap (7/16-14 x 1")
	6	145-0358	1	Adapter, Carburetor
•	7	145-0410	1	Body Assembly, Throttle
	8	150-0638	2	Joint, Ball
	9	115-0025	4	Nut, Hex (1/4-28")
	10	850-0040	2	Washer, Lock (1/4")
	11	520-0517	1	Stud
	13	850-0055	2	Washer, Lock (7/16")
	14	145-0185	2	Gasket

For components contact your nearest impco dealer or impco Division, 16916 Gridley Place, Cerritos, California 90701.

MUFFLER INSTALLATION


179-0260

(



REF. NO.	PART NO.	QTY. USED	DESCRIPTION
1	155-0989	1	Muffier
2	140-0757	2	Clamp
3	155-0997	1	Shield, Muffler Heat
4	155-0789	2	Support, Muffler
5	800-0026	6	Screw, Hex Head Cap (5/16-18 x 3/4")
6	850-0045	10	Washer, Lock (5/16")
7	862-0002	10	Nut, Hex (5/16-18 x 3/4")
8	155-1003	1	Tube Assembly, Exhaust
9	154-0570	1	Flange, Union - Manifold
10	526-0172	4	Washer, Flat
11	800-0028	4	Screw, Hex Head Cap (5/16-18 x 1")

ENGINE CONTROL MONITOR (12 VOLT PENN STATE) SETS WITH ONE FAULT LIGHT



REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION
	30 0-0730	1	Monitor, Engine Control - Complete
K1, K2	307-1039	2	Relay
C2,5	355-0005	2	Capacitor (.22 Mfd.)
C3	356-0040	1	Capacitor (10 Mfd.)
CR1,3,4,5,6	357-0004	5	Rectifier - Diode
CR2	359-0027	1	Diode - Zener (7.5 Volt)
CR7	364-0017	1	Rectifier - Gate Control
Q1	361-0003	1	Transistor 2N4871
Q2, Q3	362-0025	2	Transistor - Field Effect 2N5457
Q4	362-0008	1	Transistor - Silicon (PNP) 2N3702
R1	350-0536	1	Resistor (1000-Ohm)
R2	35 0-0526	1	Resistor (150-Ohm)
R3	350-0 552	1	Resistor (22,000-Ohm)
R4	30 3-0169	1	Potentiometer (3.5 Megohm)
R5	35 0-0572	1	Resistor (1.0 Megohm)
R6	350-0 505	1	Resistor (2.7-Ohm)
R7	350-0 517	1	Resistor (27-Ohm)
R8, R9	350-0529	2	Resistor (270-Ohm)
R10	350-0540	1	Resistor (2,200-Ohm)
R11	35 0-0971	1	Resistor (220-Ohm)

SPECIAL PARTS LIST FOR KB AND KR SERIES PENNSYLVANIA APPROVED GENERATING MODELS

Refer first to this list for Pennsylvania Approved Models. Parts not in this list refer to the main parts list (Key 1 for KB and Key 2 for KR). When referring to the main parts list, reference to Spec letter or voltage also applies to these models.

These models are recognized by the numbers 30 (Gasoline Fuel), 31 (Gaseous Fuel), or 131 (Liquid Petroleum Fuel) appearing in the model. These numbers may appear just before or after the diagonal line (/). The number appearing after the diagonal line signifies a standard Pennsylvania Approved model. (Example: 65.0KB-15R/131Q)

REPLACEMENT ENGINE

REF.	PART NO.	QTY. USED	PART DESCRIPTION
	100-0869	1	Key 1, International Harvester Co. Model UV-401
	100-0870	1	Key 2, International Harvester Co. Model UV-549
	100-0854	1	Key 1, International Harvester Co. Model UV-401-LPG Fuel Only
	100-0855	1	Key 2, International Harvester Co. Model UV-549-LPG Fuel Only

NOTE: See Standard parts list for general description.

CONTROL GROUP (ENGINE INSTRUMENTS PORTION)

REF.	PART NO.	QTY. USED	PART DESCRIPTION
3	SWITCH, SELE	CTOR	
	308-0138	1	Spec N through P
	308-0327	1	Begin Spec Q
18	300-0730	1	Monitor, Engine Control
			(See Separate Group for
			Components)

CONTROL GROUP (AC OUTPUT PORTION)

REF.	PART	QTY.	PART
NO.	NO.	USED	DESCRIPTION
3	320-0307	1	Lock, Circuit Breaker Handle